


ASSEMBLY INSTRUCTIONS


DINING BENCH



N715P383052

IMPORTANT NOTE :


- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE BENCH IS FULLY SET-UP



PART LIST FOR ONE BENCH

HARDWARE LIST FOR ONE BENCH

12



SEAT BENCH (1pc)

A



Ø4" x 38mm

SCREW (6pcs)


I



Ø5/16" x 60mm

BOLT (8pcs)

13



LEGS BENCH (2pcs)


F



Ø5/16" x 13mm

SPRING WASHER (8pcs)

14



LEGS BENCH (2pcs)


G



Ø5/16" x 19mm

FLAT WASHER (8pcs)

15



SHORT STRETCHER (2pcs)


K



Ø10" x 30mm


WOODEN PEGS (2pcs)

16




LONG STRETCHER (1pc)

J




4mm
ALLENKEY (1pc)

ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)




ASSEMBLY INSTRUCTIONS

Step 1



I	Ø5/16x60 	8PCS	F	Ø5/16x13 	8PCS
J	4x58 	1PC	G	Ø5/16x19 	8PCS



K	Ø10x30 	2PCS	A	Ø4x38 	6PCS
----------	--	------	----------	---	------

ASSEMBLY INSTRUCTIONS

Step 3

