

INSTALLATION
Product Manual




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product.follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.










For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.


Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.





When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 11+4	B x 22	C x 23	D x 1	E x 2
 M6 x 12 mm	 M6 x 60 mm	 M5 x 12 mm		
F x 2	**G x 4**	**H x 2**	**J x 4**	**K x 4**
	 M4 x 4 mm			 M4 x 10 mm
L x 4	**M x 4**	**N x 2**	**P x 4**	**Q x 1**
				
R x 1	**S x 1**	**T x 1**		
 M10	 M16			




⚠WARNING



















Children have died from furniture tipover.To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand,climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


This is a permanent label.
Do not remove!




ASSEMBLED BY 2 ADULTS

1  x 1	2  x 1	3  x 1	4  x 1
5  x 1	6  x 1	7  x 1	8  x 1
9  x 1	10  x 1	11  x 1	12  x 1
13  x 1	14  x 1	15  x 2	16  x 1
17  x 1	18  x 1		


1


Q x 1	R x 1	
	 M10	


As shown in the figure, first remove the nuts inside the iron plate 5.
The removed nuts and the L-shaped iron sheet will not be used later.
The screw A will be used later, so please don't discard it.
After removal, separate the iron plate 5 from the stainless - steel plate 6.




×4








2


B x 8	Q x 1	
 M6 x 60 mm		

As shown in the figure, use screw B to connect the side plates 1 and 2 with the iron pipes 3 and 4.
Please pay attention to the installation direction of the iron pipes 3 and 4..




3


As shown in the figure, put the iron plate 5 over the side plates 1 and 2.





4

A x 8	Q x 1	
 M6 x 12 mm		


As shown in the figure, put the iron plate 6 over the iron plate 5, and then install screw A to fix it.




5

C x 13	T x 1	
 M5 x 12 mm		


Place the iron plates 7 and 8 in the positions shown in the figure, and then install screw C to fix them.





6

B x 2	D x 1	Q x 1	
 M6 x 60 mm			


As shown in the figure, use screw B to fix the handle D on the plate 1.





7

C x 4	T x 1	
 M5 x 12 mm		

Place the iron plate 10 in the position shown in the figure and then install screw C to fix it.









8

C x 6	K x 4	L x 4	T x 1	
M5 x 12 mm	M4 x 10 mm			


As shown in the figure, use screw C to fix the iron plate 14 and the iron pipe 15.
Use screw K to fix the iron hook L on the iron pipe 11.




9

A x 4	Q x 1	
 M6 x 12 mm		


As shown in the figure, use screw A to fix the iron pipes 11 and 12 to the plate 2.




10

A x 3	Q x 1	
 M6 x 12 mm		


As shown in the figure, use screw A to fix the iron plate 13 to plate 2.




11

B x 4	Q x 1	
 M6 x 60 mm		


As shown in the figure, use screw B to fix the iron pipe 15 to plate 2.




12

B x 8	Q x 1	
 M6 x 60 mm		


As shown in the figure, use screw B to fix the iron frame 16 to the iron pipes 11, 12 and 15.







13

A x 4	Q x 1	
 M6 x 12 mm		


As shown in the figure, use screw A to fix the iron plate 13 and the iron frame 16.




14

G x 4	H x 2	J x 4	T x 1	
 M4 x 4 mm				


As shown in the figure, use screw G to fix the handle H to the iron plates 17 and 18, and press the four accessories J into the pre-drilled holes.




15

M x 4	N x 2	S x 1	
		 M16	


As shown in the figure, install the casters M and N on plates 1, 2 and the iron frame 16, and then tighten them with a wrench.







16


P x 4





As shown in the figure, install the accessory P on the plates 1 and 2 according to the steps in the figure.
Then, place the iron plate 9 diagonally into the cabinet and lay it flat on the accessory P.













17

E x 2	F x 2	
		

As shown in the figure, install the gasket F on the accessory E.
Then, connect the iron plate 17 and the iron pipe 3 through the accessory E.
After that, press the small protrusion above the side plate 17 and then snap this small protrusion into the hole below the iron plate 5.
Repeat this installation step for the iron plate 18.





WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.

- The product must be used in accordance with the instructions provided. For health reasons.

- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.

- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.

- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
  In all circumstances please save all packaging material and paperwork for the order.
  Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.