





USER MANUAL




Caution: Do Not Exceed Maximum Listed Weight Capacity.
Serious Injury or Property Damage May Occur!

PARTS LISTING


#1 x1




#2 x1




#3-L x1




#4-R x1




#L x1




#R x1




#A x1




#B x1




#C-L x1




#C-R x1




#D x1




#E x1




#H x1




#F x1



#G x1




#M x2




M6x80mm

#N x1




PASO 1




Remove the accessories from the iron frame at the bottom of the cushion


PASO 2




PASO 3




PASO 4




PASO 5




PASO 6




PASO 7




Tighten the cloth strip at the back of the seat cushion and stick it with Velcro




PASO 8




PASO 9




PASO 10



PASO 11



PASO 12



PASO 13

