















ASSEMBLY INSTRUCTION




Loosely hand-tighten screws when fitting the table base; fully tighten all only after the full frame is aligned and assembled.

Parts & Tool List


①x1 	②x1 	③x1 	④x1 	⑤x2 	⑥x2 
⑦x2 	⑧x2 	⑨x2 	⑩x2 	⑪x2 	
Ax2+1  M6*70mm	Bx4+1  M6*45mm	Cx4+1  M6*30mm	Dx8+1  M6*20mm	Ex26+1  M6*12mm	Fx4+1  M6
Gx8+1  Ø4*15mm	Hx4  Ø30*M6*15mm	Ix1  S10	Jx1  S4		




3




4




5



6



7



Hx2




Dx2



Jx1

8



Hx2




Dx2



Jx1

9



Ax2




Ex4



Jx1

10



Bx4



Jx1




Fx4




Ix1


11




12




13



14



15



16

