

Care Instruction:

1. Please check and ensure whether the quantity of all the parts and hardware are correct or not by the parts list in the manual before assembling.
2. Please follow all the steps in this manual during assembling.
3. In case of messing up the hardware to the correct position, please do not mix all the hardware together while assembling.
4. Do not tighten any single bolt before it is placed in the right position. Then please tighten them separately after all the bolts are placed in the right position.
5. The maximum load of the product is 90KG.
6. Please do not hesitate to contact with our staff in Customer Service Department for any problems you meet during assembling.

Advice of use:

For maximum quality, re-tighten the screws when necessary.

Wipe clean with a cloth dampened in a mild cleaner.

Wipe dry with a clean cloth.



DO NOT ASSUME CHILD SAFETY WITH ANY PIECE OF FURNITURE!

Do not allow children to climb on furniture. Improper use can cause death or serious injury. Furniture straps fastened to a wall can also be used to help ensuring safety.


Damaged parts or furniture putting together incorrectly can lead to serious injuries. Please make sure to follow instructions correctly.

ROZHOME

ROZHOME

*Design Comes from Life, our
furniture will make your life
better.*

DINING CHAIR




4xA
M6*16




4xB



1xC



1x①



1x②

