




ITEM NO. DKHD1858

Scan for manual,
video & advice.



If you have any questions or concerns,
don't hesitate to reach out to us.

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)
Email: customerservice@hulalahome.com

MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.


Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :

This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
200 LBS



Installation:
30 minutes.



Two Person



Before You Start

Please follow the steps below:

-  Unbox the package and check if all parts and accessories are complete.
-  If you find something missing, stop assembly and contact your supplier immediately.
-  Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
-  NOTE: Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Warranty


-  We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.
-  Are you having difficulty with assembly? Missing parts? Please send email with your order number to **customerservice@hulalahome.com**
-  For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.


Exploded Diagram

Please confirm that you have received all the parts in the box and start the installation.




Parts List

A ×1



Panel


B ×2



Side panel


Hardware List

1 ×4




Anti-tip component

2 ×4+1




Self-tapping screw
D4x20mm

3 ×2




Hardware pack

4 ×4




Expansion pipe
L30mm

5 ×4+1




Self-tapping screw
D4x40mm

6 ×1




Screwdriver

7 ×1




Hexagonal socket wrench
M5

8 ×12+1



Screw rod
M8x35mm

9 ×12+1




Flat gasket
M8mm

10 ×12+1




Spring gasket
M8mm

11 ×10+2



Felt pad

12 ×1



Power socket

13 ×2+1




Self-tapping screw
D3.5x12mm

ASSEMBLY INSTRUCTIONS

Step 01


Pass the screw (8) through the spring washer (10), then through the flat washer (9), and finally through the panel (A) and the side plate (B) to assemble them. Lock them in place with an internal hexagonal wrench (7).


7	 x 1	M5	8	 x 6	M8x35mm
9	 x 6	M8mm	10	 x 6	M8mm



Step 02



Pass the screw (8) through the spring washer (10), then through the flat washer (9), and finally through the panel (A) and the side plate (B) to assemble them. Lock them in place with an internal hexagonal wrench (7).

7	 x 1	M5	8	 x 6	M8x35mm
9	 x 6	M8mm	10	 x 6	M8mm




Step 03

Attach the felt pad (11) to the corresponding position on the side panel (B).




Step 04




Open the flip cover in the direction indicated by the arrow.



Step 05


1. Pass the power socket wire (12) through the rectangular hole corresponding to the panel (A).
2. Assemble the self-tapping screw (13) through the power socket (12) and the panel (A), and secure it with a screwdriver (6).




12	 x 1	Power socket	6	 x 1	Screwdriver
13	 x 2	D3.5x12mm			



Step 06


Pass screw (2) through the anti-fall part (1) and insert it behind the panel, then tighten with screwdriver(6).



2	 x 4	D4x20mm	6	 x 1	Screwdriver
1	 x 2	Anti-tip component			




Step 07

Install Anti-tip device (1) to the wall in this step.


5	 x 4	D4x40mm	6	 x 1	Screwdriver
1	 x 2	Anti-tip component	4	 x 4	L30mm



1. Drill a hole in the wall with an electric drill.



2. Tap the plastic wall anchor into the hole with a hammer.



3. Secure the Anti-tip device 1 to the wall with screws 5.

Step 08

⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install anti-tip device provided.
- NEVER exceed the maximum size and weight of the TV shown in the instructions.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.




***This is a permanent label.
Do not remove!***

3



x 2

Hardware pack



WWW.HULALAHOME.COM

Email: customerservice@hulalahome.com

Call us: +1(833)324-2464 (8 AM to 5 PM PST Monday-Friday)