



ABOUT

For more than 20 years we created outdoor furniture with thoughtful design made right, and this philosophy permeates everything we do. Our products enhance commercial and residential spaces, creating outdoor living experiences that stand the test of time.

Cleaning & Care

DESCRIPTION

Tekwood is a wood-alternative developed from polystyrene, an HDPE material with foam additives. Designed for the outdoors, Tekwood provides the look of wood without the weathering process or maintenance.

CARE AND MAINTENANCE

Tekwood products should be cleaned using a mild, non-abrasive cleanser and rinsed well. For deep cleaning, use a non-abrasive cleanser with a plastic scour sponge or pad, such as Scotch-Brite.™ To help prevent staining, use a furniture polish or protectant that is labeled safe for plastic materials prior to use and as part of routine maintenance. The color and grain run throughout the material so minor scratches can be sanded. Over time, Tekwood's color may darken slightly if exposed to sun and other natural elements. This process cannot be reversed, but does not affect the structural integrity or aesthetic of the product. To prolong this process, We recommends bringing furniture indoors or covering when not in use or during non-seasonal months.

SUN EXPOSURE DISCLAIMER

When exposed to direct sunlight, magnification from the sun can cause burn marks on Tekwood. To avoid these burn marks, do not use certain glass or stemware that could increase the magnification. Also, avoid leaving lighters, matches or cigarettes directly on Tekwood.

WARRANTY

warrants all outdoor furniture and accessories to be free from manufacturing defects in materials and workmanship. Provided the furniture is assembled correctly and is subjected to normal use, we will cover your outdoor furniture under a five, three, or one year warranty as applicable. For more details regarding the warranty.

GENERAL CLEANING

Tekwood can be cleaned with a cloth using most any household cleaning solution, even dish washing liquid. Rinse well after cleaning.

Recommended:
303® Multi-Surface Cleaner



DEEP CLEANING

For stubborn grease stains, scrub lightly with a plastic scour sponge or pad following general cleaning instructions.

Recommended:
Scotch-Brite® Scour Sponge or Heavy Duty Scour Pads



PROTECTION

A routine application of a furniture polish or protectant that is labeled safe for plastic materials is recommended to provide resistance to stains.

Recommended:
303® Aerospace Protectant

