


ASSEMBLY INSTRUCTION

MODEL NUMBER : 754



WARRANTY:

We stand behind our products & service with confidence! If parts damaged or missing please feel free to contact us for a FREE REPLACEMENT. We warranty this product to be free from defects in materials. This warranty covers one year from the date of original purchase.

NOTES:

- The item is only intended to be used indoors. The product must be assembled and used in accordance with the provisions of the manual.
- It is recommended that assembly is undertaken by about 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined. Estimated assembly time is 30 minutes.










WARNING:

- **WARNING FOR YOUNG CHILDREN** - This product contains small components, please ensure that they are kept away from small children while assembling.

After-sales support email: after-saleservice@outlook.com

1

PARTS LIST

A	B	C	D	E	F	a	b	c
								
2PCS	4PCS	2PCS	1PCS	1PCS	1PCS	1/4*28 10PCS	1/4*13 8PCS	1PCS


IMPORTANT:

Please check parts list before you start to assembly. If parts damaged or missing. Contact your seller for a FREE REPLACEMENT. Please provide your order number, a brief message about the issue, and your shipping address. Thank you!

After-sales support email: after-saleservice@outlook.com

2


NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED



After-sales support email: after-saleservice@outlook.com

3

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED



IMPORTANT:Please completely tighten all the bolts and nuts.

After-sales support email: after-saleservice@outlook.com