


ASSEMBLY INSTRUCTION




MODEL:ROSSO OUTDOOR DINING TABLE



No	DESCRIPTION	IMAGE	Q'TY
A	Bolt (ϕ 8x20)		6pcs
B	Washer (ϕ 23x8x1)		3pcs
C	Allen Key		1pc



STEP1

Put the base stand on the ground, after put conector on the base, checking bolts and make sure they are even, please tighten the bolts fully



STEP2

Put the top on the base, after checking bolts and make sure they are even, please tighten the bolts fully



Completed Assembly

Adjusting Floor Levelers

Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

Adjust floor levelers

Check for stability- Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

Locate the levelers- These are small adjustable feet found at the bottom corners of your furniture.

Adjust as Needed- Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.

If you need further adjustment, repeat the process in small increments.

