


# ASSEMBLY INSTRUCTION

## ASSEMBLY PROGRAM



## PARTS x QTY

|                |                |
|----------------|----------------|
| <b>AX1</b><br> | <b>Gx5</b><br> |
| <b>BX1</b><br> | <b>Hx7</b><br> |
| <b>Cx2</b><br> | <b>Ix4</b><br> |
| <b>Dx1</b><br> | <b>Jx1</b><br> |
| <b>Ex1</b><br> | <b>Kx1</b><br> |
| <b>Fx1</b><br> | <b>Lx1</b><br> |