












# ASSEMBLY INSTRUCTIONS

## Outdoor Moon Chair

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.


PARTS LIST			
ITEM	DESCRIPTION	SKETCH	QUANTITY
HW1	Bolt M6*15		4 PCS
HW2	Bolt M6*38		4 PCS
HW3	Washer		16 PCS
HW4	Nut		8 PCS
HW5	Wrench		1 PC
HW6	Allen Key		1 PC
A	Chair Back		1 PC
B	Chair Seat		1 PC
C	Chair Bottom		1 PC
D	Cushion		1 PC




## ASSEMBLY INSTRUCTIONS

Do not fully tighten bolts until assembly is complete.


### STEP 1



### STEP 2



### STEP 3



**CLEANING INSTRUCTIONS:** clean with a soft cloth, brush or lightly vacuum.

### ADULT ASSEMBLY REQUIRED

If you are missing any parts or have any questions regarding assembly, do not return this item to the retailers store. Please call our toll-free, customer service number and have this assembly manual open to the parts list ready to provide the model name, number and part name or number.



**WARNING:** This product may contain small components, please ensure they are kept away from small children.