












ASSEMBLY INSTRUCTION

COUNTER HEIGHT DESK WITH FAUX MARBLE TOP & USB

A	Side Frame	B	Side Panel	C	Stretcher	D	Wood Top
							
2pcs		2pcs		1pc		1pc	
E	USB	F	Bolt 1/4" x 1-1/2"	G	Bolt 1/4" x 5/8"	H	Bolt Cover 1/4"
							
1pc		10pcs		6pcs		10pcs	
I	Screw 12mm	J	Allen Wrench 1/4"				
							
2pcs		1pc					




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

***** Do not tighten screws & bolts until the entire unit is completely assembled.**


1

Attach Side Panel (B) to Side Frame (A) by Bolt (F) and Allen Wrench (J) as shown.




2


Attach Stretcher (C) to Side Frame (A) by Bolt (F) and Allen Wrench (J). Then cover the bolt head by Bolt Cover (H) as shown.



- 3** Attach assembled metal base to Wood Top (D) by Bolt (G) and Allen Wrench (J) as shown.



- 4** Attach USB (E) to Wood Top (D) by Screw (I) as shown.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.