


A4正面



第4页

第1页

A4反面

Tips: Don't tighten every screw until you get them all started in any one area.
F14BN001&F14GN002/F14KN003
3-Piece Teslin Patio Rocking Chairs Set

Item no.	Reference Image	Description	Qty.
A		Arm	4
B		Seat back	2
C		Front arm support	2
D		After arm support	4
E		Seat back support	2
L		Table top	1
J		Table end	2
M		Glass top	1
N		Socket head cap screw	8

Step 1:

Step 2:

Step 3:

Step 4:

Item no.	Reference Image	Description	Qty.
P		Socket head cap screw	12
Q		Screw Socket head cap screw	8
R		M6 Nut	16
S		Flat washer	36
T		Plastic washer	12
V		4-mm Allen key	1
W		Wrench	1

Step 5:

Step 6:

第2页

第3页