



**Instruction Manual**  
Table Lamp



Overview



1

NO.	Name
A	Bulb E26 (not included)
B	Finial
C	Lampshade
D	Harp
E	Socket assembly
F	Lamp base
G	Power cord




2

Assembly Instruction

1) Pull out the power cord until Socket Assembly reaches Lamp base


2) Rotate Socket Assembly counter-clockwise by two turns

3) Screw Socket Assembly onto Lamp Base


3

4) Insert Harp into Saddle




4

5) Assembly Lampshade as it shows below



5

6) Install Bulb(not included), then put Lampshade onto Harp and tighten it with Finial



6

Product Specifications

Input voltage	120V
Rated power	100W MAX
Lamp socket	E26
Cord length	5 ft.
Overall size	27.5"H X 14"W

Product Packaging


Lampbase X 2  
Lampshade X 2  
Harp&Finial X 2  
Manual X 1

7

Safety Warning:

**BULB TYPE:**  
Use only the bulb type and wattage indicated on Wattage Label placed on or near socket.  
**WARNING: NEVER EXCEED MAXIMUM WATTAGE**  
Indicated as bulb may cause fire.

**CAUTION:**  
This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature. This plug can be used in a polarized outlet only one way. If plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician.  
**DO NOT ALTER THE PLUG!**



**PROPER LAMP CARE:**  
Use a soft cloth to dust your lamp on a regular basis. Never use chemicals or an abrasive cleaner, to do so may damage the finish on your lamp.

**TROUBLESHOOTING:**  
If fixture does not work:  
1. Turn off electrical power and check all wire connections.  
2. Check fuse or circuit breaker and replace if necessary.  
3. Check to make sure light bulb is in working order.