



成品尺寸：105*148mm

对折页

CEILING LIGHT USER MANUAL



COMPONENTS AND PARTS



Light Body




Mounting Plate




Set Screws x 44




Remote control



Small Glass Panels x 22



Big Glass Panels x 22




OFF

- Read instructions carefully and turn electricity off at main circuitbreaker panel before installation.
- Before installation, make sure all parts are included. If any part is missing or damaged, do not attempt to assemble, install or operate the product.


- 1 -

INSTALLATION STEPS

Step1: Installation Of Light Stand




Fix the mounting plate to the ceiling.




Connect the wires. Feed the ceiling canopy over the mounting plate and secure it with screws.

Step2: Installation Of Light Body




Adjust the steel wire rope to the required length.




Install the set screws onto the glass panels, then insert the panels into the corresponding sized holes.


Step3: Installation of Chandeliers



Pass the lamp holder wire through the hanging light stand and lock it with the hanging chain head.



Completed



No function — Night light

Brightness+ — Color Temperature +

Color Temperature+ — Code Pairing

Brightness- — No function

No function — Change color temperature to 3000K /4500K /6000K

50% brightness — Light ON

Light OFF — OFF

NOTICE:
This remote control does not contain batteries. Please insert **2x1.5V** batteries before use.

NOTE:
If remote control no function, please match code as below:
Turn on the wall light switch, quickly long press the "SETUP" key within 5 seconds. The light flash, means the code matching is successful. Otherwise, turn off the main power supply of the lamp and then reoperate this step until the light flashe and the code matching is successful.

- 2 -

- 3 -