# ASSEMBLY INSTRUCTION

HARDWARE UST

| CODE | PARTS | QTY. | CODE | PARTS | QTY. |
|---|---|---|---|---|---|
| A |  | 1PC | C |  | 1PC |
| B |  | 1PC | D | | 1PC |
| | | | E |  | 1PC |
| | | | F | | 4PCS |

## Step 1




## Step 2




## Step 3