

General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.

Notes

- Please check and ensure all the components are intact before the assembly and strictly adhere to the instructions. Incorrect assembly may result in a risk of injury.
- Damaged components may influence the safety and function of a product. Never use the product if any component is missing or defective.
- When assembling the legs, correctly position all screws into the holes and keep the bottom of the legs at the same level, then gradually tighten them.
- Make sure the legs are adjusted to be level.
- This item is only intended to be used indoors and designed for use by one person at a time.
- The maximum static load capacity of the product is 110 kg.
- Note: Please place this dining chair on level ground, and keep all 4 feet in contact with the ground at all times to prevent falling during use. Do not perch on the front edge of the seat to avoid falling forward; sit in the chair completely. When bending to pick up items, please pay attention to the risk of falling forward.
- The plastic feet are suitable for most kinds of flooring (ceramic tile, wooden floor, PVC ground, carpet, etc), please dry it after contacting with water.
- Do not stand on the chair or use it as a step stool or ladder as it may result in physical injury or damage to the product.
- Do not expose this item to direct sunlight and never touch with sharp objects, which may cause damage to the product.
- Periodically inspect the tightness of the screws. If necessary, retighten to ensure structural integrity.
- For daily care, the PU cover can be cleaned with a soft damp cloth and wiped dry with a clean, dry cloth. If necessary, please use a suitable leather-care agent. Suede fabric cover can be cleaned with dry foam or mild detergents.

Warnings

- Please use the chair as intended. Improper use of chairs will cause accidents if as a climbing tool. Children need to be accompanied by an adult.
- Any change or modification of the product may affect its safety performance. Pay attention to the danger of injury!
- During the assembly process, keep children away from the work area. The product parts include screws and other small parts. Swallowing or inhaling them can be fatal.
- Keep packaging materials (such as non-woven fabric, plastic bags, bubble bags, etc.) out of the reach of children, especially babies since packaging materials often have unforeseen hazards such as the risk of suffocation.

A × 1 	**B** × 1 	**C** × 2
D × 1 	**E** × 9  M8 × 55 mm	**F** × 9
G × 9 	**H** × 1 	**I** × 4 

1

- Don't tighten all the screws.





E		5PCS
F		5PCS
G		5PCS

2

- Don't tighten all the screws.





E		4PCS
F		4PCS
G		4PCS

3



- Please press down on the seat surface to level the legs on an even floor.

4

- Then, tighten all screws firmly.





5



I 4PCS

6



- Screw in the adjustable feet to keep the chair balanced.