







ASSEMBLY INSTRUCTION

NO.	DRAWING	QTY	NO.	DRAWING	QTY	NO.	DRAWING	QTY
A		1	B		1	C		1
D	 M6*20MM	8	E	 M6	8	F		1
G		4						

Step1. 	Step2. 	Step3. 	Step4. 
--	---	--	--

The washer(E) is used to adjust the stability of the whole chair.
When the chair is not level, you can add the washer(E) in the leveling bolt according to the actual situation.