



ASSEMBLY INSTRUCTIONS




IMPORTANT REMARKS




Never climb or lean on the furniture.
You may suffer serious accidents.



Use the packaging to cover the
assembly area and separate
all parts.



Identify the parts by observing the
number printed on their edges.




CARE INSTRUCTIONS



Wipe clean using a damp cloth and a mild cleaner.
Do not use abrasive and chemical products.



HANDLING




Move the piece carefully, don't drag it. Ask
for someone else's help to do so.

HARDWARE



Identify and separate the hardware used in the assembly. There's a label on each package identifying the parts and where to use them.



WIRE CHANNEL-1x

COD. 0348-1x

COD. 2088-8x

SUPORT - 1x


COD. 4157-10x



A




B



C

SUPORT TV

D



E


COD. 9070-4x

COD. 1668-3x

COD. 0160-20x

LED -1x

COD. 3706-16x




F




G



H



I




J

COD. 3527-6x


COD. 3557-12x

COD. 6024-4x

COD. 9069-8x



K




L



M




N




DESCRIPTION


W:71.26 inches H:52.20 inches D: 8.46 inches
L:1810mm A:1328 P:215 mm




PART	QUANTITY	DESCRIPTION	BOX
12	01	TOP PANEL	01
13	01	CENTRAL PANEL	01
14	01	PANEL WIRE CHANNEL	01
15	01	BACK PANEL	01
16	01	TOP SHELF	01
17	02	SIDE BATTEN	01




01

COD. 0348 B	COD. 4157 E	COD. 9070 F	COD. 1668 G	COD. 0160 H	KIT LED I	COD. 3706 J	COD. 3557 L
							





02





Use the PVA glue before screwing.

03





COD. 3527	COD. 6024
K	M
	





04




Measurement to drill the wall.



06

**ATTENTION**

Pass the cables through the back before Panel.



07

