



SATCO Starfish
Security
Floodlight
Camera 65-
920 & 65-921

Prepare the Starfish Security Floodlight Camera




Pairing mode - Indicator should be quickly flashing red/blue.

If the indicator is not quickly flashing red/blue; **press & hold the reset button for 5 seconds**, then release. The Security Camera will reset and the indicator will then begin to flash red/blue. It is ready to be paired.




Pairing the Starfish Security Floodlight Camera via QR Code


1. On the Home Panel, Tap “+” in upper corner, to add a new device.
2. Select Add Device from the list.
3. Choose Floodlight Camera from the options.



Confirm the indicator light is blinking rapidly, tap the circle to confirm. Tap Next.







Enter WiFi Network & Password. Tap Next.






QR code is generated. Place QR code 6 to 8 inches in front of the camera until a prompt is heard from the camera. Once prompt is heard, tap “I Heard a Prompt”.

The Camera will begin to pair with the Network.

Pairing the Starfish Security Floodlight Camera Manually (default)



Pairing the Starfish Security Floodlight Camera Manually con't



Click icon to edit device name and/or assign a room. Otherwise, click done.

You are now ready to use your Starfish Security Floodlight Camera.


Home Panel



Press for
main settings

Main Settings

Press to go
back to
Home Panel



Press to rename,
assign room

Press to view
Basic Functions

Press to
change settings

Press to view
settings

Press to
change to
Auto/On/Off

Press to
change settings


Main Setting Con't

Press to go back to Home Panel

Press to change settings

Press to Share Device

Press to remove device



The screenshot shows the 'Settings' app interface. At the top, there's a status bar with the time 11:41, signal strength, Wi-Fi, and 88% battery. Below the title 'Settings', there's a list of settings categories: PIR Settings (with a 'High >' option), Storage, Storage Settings (with a '>' option), Recording, Recording settings (with a '>' option), Offline Notification, Offline Notification (with a green toggle switch), Others, FAQ & Feedback (with a '>' option), Share Device (with a '>' option), Add to Home Screen (with a '>' option), Device Update (with 'No updates available >'), and Remove Device at the bottom.


Will advise when Security Floodlight is offline. Press to change setting.

Basic Function Settings

Press to go back to Main Settings

Press to turn on or off.


Press to change Talk Setting



The screenshot shows the 'Basic Function Settings' app interface. At the top, there's a status bar with the time 11:42, signal strength, Wi-Fi, and 88% battery. Below the title 'Basic Function Settings', there's a list of settings: Status Indicator (with a green toggle switch), Flip Screen (with a grey toggle switch), and Talk Mode (with 'One-Way Communication >').

Talk Mode

Press to go
back to Basic
Function
Settings




Choose your
setting

Detection Alarm Settings

Press to go back
to Main Settings

Press to change
sensitivity

Press to edit
area




Press to turn
on or off.

Press to turn
on or off.


Press to turn
on or off.

Press to create
a schedule.



Surveillance Area Setting adjust.

Storage Settings




The screenshot shows the 'Storage Settings' screen with a back arrow at the top left. The status bar at the top shows the time 5:07, signal strength, Wi-Fi, and battery. The screen lists storage capacity information: 'Storage Capacity' (Total Capacity: 28.80G, Used: 28.70G, Remaining Capacity: 0.10G). At the bottom, there is a 'Format' button.

Press to go back to Main Settings. View Only.

Press to format SD Card.


Record Settings



The screenshot shows the 'Recording settings' screen with a back arrow at the top left. The status bar at the top shows the time 11:43, signal strength, Wi-Fi, and 88% battery. The screen has three toggle switches: 'Local Recording' (on), 'Mute Recording' (off), and 'Recording Mode' (set to 'Event Recording'). There is also a 'Schedule' option with a right arrow. A red box highlights the 'Recording Mode' option.

Press to go back to Main Settings

Press to change to Event Recording or non-stop.



The screenshot shows the 'Recording Mode' screen with a back arrow at the top left. The status bar at the top shows the time 4:11, signal strength, Wi-Fi, and battery. The screen has two options: 'Event Recording' (selected with a blue checkmark) and 'Non-Stop'.

Press to save and go back to Record Settings

Change to Event Recording or Non-Stop.


Home Panel



Press for additional functions.

Swipe down to see more recent events

Notifications (Events)




Press to view all events & videos

Picture of event. Tap to view picture (not video).

All Notifications (Events)

Press to go back to Home Panel

Swipe down to see more events




To Select an Event or Select All Events

Tap "View" to see video of event

Delete Notifications (Events)


To Select All or Cancel All



To Select or Cancel single event

Delete All Selected Items

View All History (Video)



Tap "History" to view All History (Video)

History / Playback Non-Stop Recording

Press to go back to Home Panel

Press to view recent date

Will load to current day at 12:00AM

Press to change/view date from Calendar

Swipe across to see desired time

History / Playback Event Recording

Press to go back to Home Panel


Press to change/view date from Calendar

Press to view recent date

Will load to current day at 12:00AM

Swipe across to see desired time/event start

Features



Resolution

Settings

Mute & Zoom

Talk

Screenshot

Record

Full Screen

Alarm

Album

Light

Private Mode

Theme Color

Motion Notifications

PIR Settings


IR Night Vision

Features

Settings	Main Settings
Zoom	Zoom in on the Live View
Mute	Mute/Unmute the Floodlight Microphone
Resolution	Set between HD/SD
Talk	Speak through the Floodlight Speaker
Screenshot	Screenshot the Live View to Mobile Device
Record	Record the Live View to Mobile Device
Theme Color	Choose Light or Dark Theme
Full Screen	Switch Live View to Full Screen
Album	View Screenshots and Recordings
Alarm	Manually Active the Floodlight Alarm
Light Control	Manually Turn the Floodlights On/Off, Dim, change CCT
Private Mode	Remotely Enable/Disable Camera Recording
PIR Settings	Adjust PIR Sensitivity & Light On Time
IR Night Vision	IR Set Night Vision to Auto/On/Off
Motion Notifications	Enable/Disable Motion Notifications
Dusk-to-Dawn Settings	Change the Dusk-to-Dawn settings
Notifications	Review past Motion Notifications
History	Review all past video




Alarm



Press to sound
Alarm on/off



Light Control



Slide to
brighten/dim
when lights are
on.

Press to turn
floodlights
on/off


Slide to adjust
color temperature
when lights are on.

Press to create
a schedule

Press to set
light time on.




Light Time On





When motion is detected at night, the flood lights will turn on. The lights will stay on for 15 seconds. To increase the time, slide to the desired time on. For example, if you would like the lights on for 1 minute, slide to 45 seconds (15 seconds + 45 seconds). For 2 minutes, slide to 1min 45 seconds (15 seconds + 1min 45sec). Press "Set"

Select Light or Dark Mode


Theme Color



Album




PIR Settings




Select PIR Sensitivity

Night Vision




Select Night Vision setting - Auto/On/Off

Dusk-To-Dawn Settings




Press to bring
up Dusk-to-
Dawn Menu



Choose
desired
setting.

View Multiple Cameras at one time




Press Camera Icon to view multiple connected cameras at one time.



Press to return to Home Panel

Select how many cameras to view at one time.



Turn device to view horizontally.