

ASSEMBLY INSTRUCTIONS


Made in China

Thank you for purchasing this product. We want to make sure it is complete and to your satisfaction. Please check all packing material carefully for small parts which may have come loose inside the carton during shipment. Hardware can be identified by bright red packaging. Separate, identify, and count all parts and hardware to make sure they match with the illustrations herein and are all present. If any part(s) are missing or defective please contact Customer Service. Contact information is given separately on parts request form. If you feel the item is defective beyond a resolution with part replacements, please return this product with your receipt to the place of purchase. If purchased from an internet retailer, please contact their customer service department. Photos and additional information may be requested to validate the claim. Product is not to be returned to the Company under any circumstance unless authorized by the Company or an authorized dealer or representative. Thank you.

ATTENTION: SOME LETTERED PARTS LISTED ON THE INSTRUCTION SHEET MAY NOT BE IN PARTS BAG AS THEY MAY ALREADY BE ASSEMBLED. CAREFULLY CHECK PARTS AND PACKING MATERIALS PRIOR TO ORDERING REPLACEMENTS.

Tools Required for assembly: Allen Wrench (provided).
Phillips Screwdriver(not provided)

WARNING: DO NOT FULLY TIGHTEN SCREWS AND BOLTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED PROPERLY.
TO PREVENT SCRATCHING THE TOP SURFACE, ASSEMBLE PRODUCT ON A SMOOTH SURFACE.
DO NOT OVER TIGHTEN SCREWS AND BOLTS.













PARTS


- (A) LEFT PANEL
- (B) RIGHT PANEL
- (C) DOOR

- (D) BACK PANEL
- (E) END PANELS(2)
- (F) SHELF

- (G) CROSSBAR
- (H) HANDLE
- (J) SIDE FRAME



HARDWARE



K

Φ 3/16"X1/2"
(21 PCS)



L

Φ 1/8"X3/8"
(2 PCS)




M

Φ 3/16"X1/2"
(2 PCS)




N

Φ 3/16"
(20 PCS)




O

(1 PC)



P

(4 PCS)




Q

(2 PCS)




R

(2 PCS)




S

(1 PC)




T

(1 PC)



U


(1 PC)




V


(1 PC)

Option 1: Step 1 - 14.




Option 2: Step 15 - 28.








STEP 1




STEP 2





STEP 3







STEP 4




STEP 5




STEP 6




STEP 7





STEP 8







STEP 9




STEP 10







STEP 11




**TO PREVENT TIP OVER,
PRODUCT MUST BE ATTACHED TO WALL**




STEP 12





STEP 13




WARNING

Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:


- Place heaviest items in the lowest drawers.
- Unless specifically designed to accommodate, do not set TV's or other heavy objects on the top of this product.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.
(OR)
- Do not defeat or remove the drawer interlock system.


Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.

This is a permanent label. Do not attempt to remove




STEP 14








STEP 15




STEP 16





STEP 17









STEP 18





STEP 19









STEP 23




STEP 24









STEP 25




**TO PREVENT TIP OVER,
PRODUCT MUST BE ATTACHED TO WALL**

STEP 26





STEP 27



WARNING

Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Place heaviest items in the lowest drawers.
- Unless specifically designed to accommodate, do not set TV's or other heavy objects on the top of this product.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.
(OR)
- Do not defeat or remove the drawer interlock system.

Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.

This is a permanent label. Do not attempt to remove

STEP 28

