

# ASSEMBLY INSTRUCTIONS

ITEM CODE : IN 4071

ITEM DESCRIPTION : **CABINET**

**1**

Reverse the cabinet top & place the leg as shown & align the leg to match the apron.



**2**

Place the bolt & washer in the cut out & tighten it with allen key provided as in Fig1.



**3**

Fix the other leg set in the similar way



**4**

Reverse the cabinet straight. Now your cabinet is ready for use



Fig.1



