USER MANUAL Solar Stair Lights

1 . Before installation, turn on the switch on the side of each light. Charging is only effective when the switch is turned on.
2.Before using it for the first time, make sure the switch is on, and charge in direct sunlight for at least 8 hours.
3. Install the solar light in an area that is directly exposed to sunlight.
4. The light will dim or flash when the battery runs out. it will work normally when fully charged.
5. The working time of solar lights becomes shorter on cloudy days or in winter because of weaker sunlight.

Operation
1: Toggle the "ON/OFF" to turn on the light, the switch is located at the side opposite the lights.
2: Install the light in an area where it can get direct sunlight.
3: The lamp will automatically turn on at night and turn off in daylight.

Installation
There are two ways to install the lights after switching on the lights.

A. Use the double sided tape on the bottom and back of each light to tape the lights to a flat surface.
B. Use the positioning plate to determine where to drill holes for the screws (and plastic anchors if needed). Insert screw leaving the screw head slightly higher than the surface. Clamp the light onto the screw head to complete installation.

Warning
1: Do not dispose of the product and batteries in fire. When the product or batteries are disposed of in fire, the heat build-up may cause an explosion.
2: Do not disassemble the product by yourself.
3: Do not soak the product in water.

Specification
Product name: Solar Light
Solar panel: Solar panel 2V/0.3W
Battery:1.2V AA600mAh
Charging time: 4-6 hours
Working time: 8 hours in summer and 5 hours in winter
Material: ABS