


ASSEMBLY INSTRUCTIONS




TOOLS REQUIRED



Allen Wrench

(Included)




Socket Wrench

(Included)



**2 - People
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!




Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Save the instructions and store
any supplied tools for later
maintenance.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

COFFEE TABEL




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

#1 1pc




Glass Top

#2 1pc



Base

#3 1pc



Pedestal

HARDWARE

#A 4pcs



Bolt 1/4" x 1-5/8"

#B 2pcs



Threaded Stud

#C 4pcs



Small Flat Washer

#D 1pc



Allen Wrench M4

#E 6pcs



Adjustable Foot
M6x16

#F 1pc



Socket Wrench M8

#G 2pcs



Nut M8

#H 2pcs





Large Flat Washer

#I 2pcs




Cover

Carton	Designation	Part		Hardware
	Glass Top	#1		
	Base	#2		
	Pedestal	#3		 #A x 4pcs  #B x 2pcs  #C x 4pcs  #D x 1pc  #E x 6pcs  #F x 1pc  #G x 2pcs  #H x 2pcs  #I x 2pcs

ASSEMBLY INSTRUCTIONS


1

Part **#1** x 1pc
 Part **#3** x 1pc
 Hardware **#B** x 2pcs
 Hardware **#G** x 2pcs
 Hardware **#H** x 2pcs




Attach studs (**#B**) to the top (**#1**), then align pedestal (**#3**) to the studs (**#B**) on the top (**#1**). Secure by using hex nuts (**#G**) with washers (**#H**).

1-1




1-2




2

Part **#2** x 1pc
 Hardware **#A** x 4pcs
 Hardware **#C** x 4pcs
 Hardware **#E** x 6pcs



Align base (**#2**) to the pedestal, then secure by using bolts (**#A**) with washers (**#C**). Attach adjustable feet (**#E**) to the base (**#2**).





ASSEMBLY INSTRUCTIONS


3

Hardware **#1** x 2pcs

Place covers (**#1**).



4



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.