









NOTICE

- *Please make sure that you have all parts indicated before you begin assembly of this item.
- *This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- *This item may require periodic tightening.
- * If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com


Parts List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat		1x
B	Front leg		2x
C	Back leg		2x
HW1	Screws 6*1*80mm		8x
HW2	Flat Washer 9mm		8x
HW3	Split Lock washer 9mm		8x
HW4	Foot glide 25mm		4x
HW5	L Wrench		1x

SAFAVIEH C O U T U R E

Model# **KNT4106**

Product Dimensions: **22"W*29"D*39"H**



WARNING:
WEIGHT CAPACITY: 275 LBS.
DO NOT STAND ON CHAIR

CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.


The use of steam or water-based cleaners may cause excessive shrinking or staining.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assemble Time: 15 minutes.



Step 1

1. Carefully turn the Seat (A) onto its side lying on a smooth scratch free surface. Insert front leg(B) and back leg(C) into the wood frame, Next use the L Wrench(5) tighten the screws (1) with washer(2) and (3) into the frame. Stick the foot glide(G) on the bottom of each leg. Then carefully turn the seat upright.