

# INSTALLATION INSTRUCTION

## Step 1



Place the big bowl onto the big base, and fix with twist clockwise.

## Step 2



Thread the pump cord plug through the big base pipe, and stuck the cord at the outlet position.

## Step 3



Put the hose in the small bowl to the pipe in the mid bowl, then rotate until it snaps.

## Step 4



Connect the water pump with the hose on the main body.



Get the pump in place, and cover with mid base onto the big bowl.

## Step 5




Connect the water pump with the hose on the main body.

## Step 6



Plug the small flower top onto the small bowl.

## final look



Installation is complete. If you have any questions, please contact customer service!

**NOTE:** If all the accessories are assembled, the power is connected but no water is coming out, or if it has been running for some time, but the water fountain fails to flow smoothly after disconnecting the power, it might be that there is air accumulation inside the water pipe blocking the flow.

### The following solutions can be tried:

Unplug the power, remove the upper water pipe of the water pump, let the air trapped in the water pipe be expelled, then reconnect the water pipe and plug in the power again.