



For turning the Chair and to prevent damage to the Chair, 02 persons may be needed to execute this action


Parts List			
No.	Picture	Description	Qty
A		Backrest Panel	1
B1		Right Leg Frame	1
B2		Left Leg Frame	1
С		Seat Panel	1
D		Cross bar	2
Hardware			
No.	Picture	Description	Qty
		Allen Key	1
2	<b>€⊃nnnnnn</b> ⊷	Short Screw (M6*35mm)	5
3	<b>}</b> ⊐ <i>ишиши</i> -	Medium Screw (M6*60mm)	3
4	<b>∄</b> ⊐ <i>₩₩₩₩₩₩₩₩₩</i> ₩	Long Screw (M6*80mm)	5


## Assembly Preparation



give you an overview of the Chair, the above picture to assemble to help you put the various parts into perspective. Please read through the instructions here below to familiarise the parts and steps before assembly.







Place the Chair right side up on a LEVEL SURFACE to see if it wobbles.

If it wobbles, lift the Chair 30cm to 50cm high from the ground.

Keep your feet and toes well away from the drop zone.

Drop the Chair freely and vertically with all four legs, hitting the ground at the same time.

This Drop Test will help to ensure that all the Bolts, Screws and gaps reach full alignment status.

Test again for evenness on a LEVEL SURFACE.

If no wobbles are found, proceed to tighten all the Bolts, Screws.

When tightening the Bolts, Screws, tighten sequentially.

Do not tighten any Bolt, Screws fully and then move towards the next one. This could cause the frame to warp.

If there are still wobbles, loosen the Bolts, Screws and execute the same drop tests.

If the Chair is not stable it could lead to damage to the product.



Inspect the Chair and make sure all parts are connected. Your Chair is ready for use.

This Chair can only be used on a flat, level surface.

Care & Maintenance
Do not clean furniture with harsh cleansers or polish.
<ul> <li>To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.</li> </ul>
K In the standard
<ul> <li>Do not write on furniture without a padded barrier to protect the surface.</li> </ul>
<ul> <li>To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.</li> </ul>
Not for commercial use. For residential use only.
Stains may be removed with mild soap solution and damp cloth.
✓