



To fully enjoy the comfort and functionality of your new sofa, please follow these steps to help it regain its original shape after unboxing:

1. Pat the Sofa: Gently pat the sofa on each side several times to assist in reshaping it. Start by patting one side, then repeat on the other.

2. Flip the Sofa: Turn the sofa over and repeat the patting process to ensure even reshaping on all sides.

3. Rotate the Sofa: Rotate the sofa 180 degrees so the back is facing down, and repeat the patting to further restore its shape.

4. Secure the Sofa: Attach the Velcro strips to the bottom of the sofa to keep it securely in place and prevent separation.

5. Lightly Tap and Press: Lightly tap, knock, and press on the sofa to help it regain its original shape and improve overall comfort. improve overall comfort

6. Smooth the Fabric: If wrinkles appear on the sofa fabric, use a garment steamer to smooth them out for a more polished appearance

