






CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly on this item.
- * This item should be assembled on a soft surface to prevent scratching/dirtying the surface during assembly.
- * This item may require periodic tightening.


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Top		1X
B	Back Panel		1X
C	Front cover		2X
D	Left Panel		1X
E	Right Panel		1X











ITEM NO.:ETG2100

Item Dimension:W20"x D12.60"x H68.10"




Part List and Hardware List


PIECE	DESCRIPTION	PICTURE	QUANTITY
F	Shelf Top		1X
G	Shelf Board		1X
H	Shelf Board		1X
I	Base		1X
HW1	Cam Bolt		40X
HW2	Cam Lock		40X
HW3	Hook		2X
HW4	Phillips Screw (M3x15mm)		4X

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.


1



HW1 x4	
-----------	---

2




HW2 x2	
-----------	---

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.

3



HW1 x2	
-----------	--

4




HW1 x12	
------------	--

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.

5



HW1 x16	
------------	--

6




HW1 x12	
------------	--

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.


EstimatedAssemblyTime: 30 minutes.

7



HW2 x4	
-----------	--

8




HW3 x2	
HW4 x4	

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.

9



HW2 x4	
-----------	--

10





HW2 x8	
-----------	--

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.


11



HW1 x8	
-----------	---

12




HW2 x4	
-----------	---


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.

13



14



HW2 x4	
-----------	--