

Assembly Instructions

Coffee Table

N735P493617

Case & Maintenance



Not for commercial use. For residential use only.



Furniture may scratch floors. We recommend using furniture pads to protect your floors.



Do not put hot items directly on furniture surface.




Do not clean furniture with harsh cleansers or polish.



Do not place furniture under direct sunlight.



Do not write on furniture near heating or cooling vents.



Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside for indoor use only.



Stains may be removed with mild soap solution and damp cloth.



Children should not climb or jump on the furniture.




Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in the box for hardware packs and legs.



Sets oftenship in multiple boxes and may arrive a day or two apart.

Coffee Table

N735P493617



Part List : N735P493617


Label	Picture	Description	QTY
1		Frame Table	1
2		Legs Table	2

Hardware List : N735P493617


Label	Picture	Description	QTY
A		Bolt (1/4" x 20mm)	8+1
B		Flat washer (1/4")	8+1
C		Allen key (M4)	1+1

Assembly Preparation

Before Beginning assembly:



A



x 8pcs + 1

B



x 8pcs + 1

C



x 1pc + 1



Read the instructions cover to cover



Have 2 adults on hand for assembly



Do not assemble on flooring or carpet




Assemble on a clean, non-marring surface (packing foam)



Save all packaging until finished

Assembly Steps



Overview



FRONT FACING


This Coffee Table have multiple parts and may require up to 20 minutes to assemble. To give you an overview of the Coffee Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly. Note: It is recommended that you have an adult partner to assist during the entire assembly process.

Step 1




- Open frame table (1) bolt 1/4" (A) and flat washer (B)
By using the Allen key (C) open olt 1/4" (A) and flat washer (B)

Step 2




Pull the two sides of the table (1) outwards and take the inner legs (2) out.

Step 3




- Assemble the frame table (1) with legs table (2)
- By using the Bolts (A) and Flat washer (B) with Allen Key(C) to tighten the Bolts

Step 4




- Adjustable Leveler

Finish



Coffee Table

N735P493617



Place the Coffee Table on a LEVEL SURFACE.
Inspect it and make sure all parts are adequately connected.
Don't push too hard, shake on the bed.
This would help to align all the parts at the joint areas.

CAUTION 1: When tightening these screws, tighten sequentially.
DO NOT tighten any screws fully and then towards the next one.
This would cause the frame to warp.
If there is still wobbles, loosen the screws and execute this same process. DO NOT
tighten any screws fully and then towards the next one.
WARNING!! IF COFFEE TABLE IS NOT STABLE, IT COULD LEAD TO DAMAGING
THE PRODUCT.
Ensure all screws are fully locked into position.
The Coffee Table is ready to be used.
Caution 2: This Coffee Table can only be used on a flat, level surface.