

Please Note:

1. Please use a grounded 3-prong outlet. Do not remove the grounding prong, use an adapter, or an extension cord
2. Upon arrival, please leave the unit upright and wait 24 hours before plugging it in
3. Children should never operate, play with, or crawl inside the appliance
4. It is recommended to have a separate circuit for the appliance. Use receptacles that cannot be turned off by a switch or pull chain
5. Do not plug or unplug the electric plug with wet hands
6. To prevent injury, use at least two people to move and install the appliance
7. Ensure proper ventilation by keeping the front of the unit unobstructed. Install it in a well-ventilated area with temperatures between 60.8 °F (16 °C) and 89.6 °F (32 °C).
8. Protect it from wind, rain, and water spray
9. Keep the appliance away from ovens, grills, or other high heat sources
10. Avoid kinking or pinching the power supply cord
11. Do not use solvent-based cleaners or abrasives on the interior