

ASSEMBLY INSTRUCTIONS:

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A FLAT SURFACE AND LINE THEM UP AS PER THE SKETCH.
2. SCREW LAMP BODY (B) ONTO LAMP BASE (A) UNTIL TIGHT
3. SCREW LAMP BODY (C) ONTO BODY (B) UNTIL TIGHT
4. INSERT HARP (G) INTO SADDLE (D).
5. PLACE SHADE (H) ONTO HARP (G) AND SECURE WITH FINIAL (I).
6. INSTALL THE BULB (F) INTO THE SOCKET (E).
7. INSERT THE POLARIZED PLUG INTO AN OUTLET, TURN ON THE SWITCH AND ENJOY YOUR LAMP.

Use a 25W 3-Way CFL Type Bulb or 150W (Maximum) Incandescent 3-Way A Type bulb.

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT TO ALTER THE PLUG.

❖ PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.

❖ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

