


ASSEMBLY INSTRUCTION




Components List


Carton:1




K ×1




L ×1




N ×1




T ×1




P ×1




J-R ×1




J-L ×1



I-L ×1






I-R ×1



O ×2



Hardware List

A	M6X20mm	B	M4	C		D		E		F	
											
x12		x1		x8		x2		x4		x1	

STEP 1




C×4



STEP 2





C×4





STEP 3

	A×4
	B×1
	D×2




STEP 4


	A×8
	B×1
	E×4




STEP 5




STEP 6




STEP 7



STEP 8




STEP 9




STEP 10


Noted: The backrest has 5 positipns. Push the backrest completely towards the seat cushion to reset the position.



Please connect the armrest plug board to the power cord.



Please hold and adjust the gear with both hands.




STEP 11




H×1


The cushion is in compression package . Just take out and plump up for hours . 48 hours is better for reaching its full size . Follow the assembly instructions to assemble after reach its full size .




STEP 12



STEP 13



STEP 14



QUESTIONS? CONTACT US:

If in any case, you are not 100% happy with the item received, would you please contact us first and give us a chance to make it right for you? All of our products are covered by warranty and we will do our best to address any of your concerns. We are dedicated to your 100% satisfaction with your order.