

ASSEMBLY INSTRUCTION

94.5"H Lighted Halloween 3D Foldable Fabric Jack-O-Lantern Outdoor Décor 420 Warm White LED Lights



Please carefully unpack and identify each component before beginning assembly. Before you begin, please refer to parts list to make sure that you have all parts. Please take care when assembling the unit and always place the parts on a clean, soft surface. If you require assistance with assembly or parts, please call 888-357-7263.




Get social with us and discover more about our products, tips and exclusive discounts!



BEFORE ASSEMBLING

1. Please check and make sure all the parts have been received.
2. Tools are not required for assembly.
3. The length of extension cord is 98 inch, please set up the product in the suitable place away from the power socket.


PART LIST

Fabric pumpkin (A)  QTY: 1	Iron pipe A and triangular support rods (B)  QTY: 1	Round metal base (C)  QTY: 1
Ground stakes (D)  QTY: 4	Screw nuts (E)  QTY: 7	Iron pipe (part of triangular support rods) (F)  QTY: 3
Zip ties (G)  QTY: 7	Transformer (H)  QTY: 1	


STEP-BY-STEP ASSEMBLY

PLEASE CAREFULLY UNPACK AND IDENTIFY EACH COMPONENT BEFORE BEGINNING ASSEMBLY. BEFORE YOU BEGIN, PLEASE REFER TO PARTS LIST TO MAKE SURE THAT YOU HAVE ALL PARTS.


STEP 1 Assemble the triangular support rods of the central bracket onto the round metal base by using screws. Then assemble the iron pipe A above the triangular support rods, and then cover the fabric pumpkin from the top.



STEP 2 Pull the fabric on the bottom and hook it up to the round metal base.



STEP 3 Finish the assembly and be ready for display.



DISASSEMBLY AND STORAGE

1. Remove all decorations.
2. Disassemble the product in reverse order of assembly.
3. Suggest to store it in its original carton box or in storage bag and keep in a cool dry place.

CAUTION

1. To be assembled by or under the supervision of an adult.
2. Keep plastic bags out of reach of children.
3. Keep away from fire or hot temperatures.
4. Do not light a candle on or near the product.
5. Do not leave lighted electric cords unattended.
6. When assembling, do not let children play around the working area.
7. Place the product on an even surface to ensure stability.
8. Keep this information for future reference.
9. Please periodically check all fittings and re-tighten as necessary.

Made in China

glitzhom^e[®]

Glitzhom^e, LLC.

Toll free 888-357-7263
customerservice@glitzhom^e.com