

TOOLS REQUIRED



Allen Wrench

(Included)



Philips Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.



	Are you missing anything?		Check out our Quick Tips!	
	Double-check all parts, hardware and accessories listed on Page 6 are accounted for.		We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!	
	Should we send any replacements?		Prep Time!	
	Are there any irregularities or flaws in the parts? We can send replacements!		Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.	

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

BED

CM716EK/CK




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.





2pcs


Side Rail

(L & R)









Footboard

1pcs

HARDWARE 22pcs 1pc 4pcs Allen Key M4 with ball JCBC Bolt M6 x 30mm JCBC Bolt M6 x 45mm 6pcs 2pcs 10pcs CSK Screw M4 x 20mm CSK Screw M4 x 32mm JCBC Bolt M6 x 60mm 10pcs 22pcs 4pcs CSK Screw M4 x 45mm Adjuster Spring Washer M6

Flat Washer Small M6 x 13 x 1.0 Flat Washer Medium M7 x 19 x 2.0 Flat Washer Large 3/8 x 25 x 1.0

0

22pcs

22pcs

2pcs


0

Carton	Designation		Part	Hardware
CM7164EK-1	Headboard	#1	1pc	
OMIT TO TELLY T	Headboard Leg Support	#2	2pcs	
	Bed Leg	#5	2pcs	#A x 1pc #B x 4pcs
	Slat with 3 holes	#6	5pcs	#C x 22pcs #D x 6pcs #E x 2pcs
CM7164EK-2	Leg Support	#7	10pcs	(%)
	Footboard	#8	1pc	#H x 10pcs #I x 22pcs
	Side Rail	#9	2pcs	#J x 2pcs #K x 22pcs #L x 22pcs
CM7164EK-3	Ear Panel	#3	2pcs	
	Ear Panel Support	#4	2pcs	

1

Part #1) x1pc

Part (#2) x2pc





Part(#1) x1pc

Part(#2) x2pcs


Hardware (#A) x1pc

Hardware #C x4pcs

Hardware #I x4pcs

Hardware (#K) x4pcs


Hardware (#L) x4pcs



3

Part (#3) x2pcs

Hardware (#G) x4pcs



4

Part(#1) x1pc

Part(#2) x2pcs

Part (#3) x2pcs


Hardware #A x1pc


Hardware (#C) x6pcs


Hardware (#I) x6pcs


Hardware (#K) x6pcs

Hardware (#L) x6pcs









Align slat (#6) to the side rails (#9), then secure by using screw (#F).

Part(#6) x5pcs

Part(#7) x10pcs

Hardware (#A) x1pc

Hardware (#C) x10pcs

Hardware (#F) x10pcs


Hardware (#H) x10pcs

ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy! Please retain this instruction manual and any order-related information for future reference

✓ Lift, don't drag! To avoid damage to product please always LIFT the product when transporting of adjusting the placement.



This product is intended for RESIDENTIAL USE ONLY and not for commercial use.