


Pendant Light Installation Guide

Please read all instructions before



INSTALLATION STEPS

1. **Turn off the power before installation.**
2. Connect the extension rods ①②③ to the lamp body and choose the proper hanging height.
3. Attach the **universal joint connector** ④ to the top extension rod.
4. Secure the **mounting bracket** ⑤⑥ to the ceiling junction box with screws.
5. Connect the wires with **wire connectors** ⑦:
--Connect the **black** to the **black/live** house wire.
--Connect the **white** to the **white/neutral** house wire.
--Connect the **ground wire** to the outlet box ground wire or **green** ground screw.
6. Place the canopy over the **mounting bracket** and secure it with **decorative cap nuts** ⑧⑨.
7. Place the **glass shade** onto the lamp holder ⑩, secure the glass shade and **metal ring** with screws ⑪. Do not overtighten.
8. Install a compatible E26 bulb into the socket. Restore power and test the light. (**Bulb not included**)

PARTS LIST

	Lamp Socket with Cord · Qty 1		Junction Box Screws ····· Qty 3
	Canopy ····· Qty 1		Wire Nuts ····· Qty 3
	Flat Washer ····· Qty 2		Mounting Bracket ····· Qty 1
	Wall Anchors ····· Qty 3		Metal Ring ····· Qty 1
	Anchor Screws ····· Qty 3		Joint Connector ····· Qty 1
			Extension Rod ····· Qty 4

SAFETY INFORMATION

- Before installation, make sure all parts are included and undamaged.
- Turn off power at the circuit breaker before installation or wiring.
- Complete fixture assembly before restoring power.
- Installation and servicing should be performed by a qualified electrician

TECHNICAL SPECIFICATIONS

Product Type:	1-Light Pendant
Mounting Type:	Hardwired Ceiling Mount
Socket Type:	E26 Medium Base
Input Voltage:	110-120V AC, 60 Hz
Maximum Wattage:	60W
Bulb Included:	No
Materials:	Metal and Glass
Use Location:	Indoor Dry Locations

TROUBLESHOOTING

- Light does not work:**
Check the bulb, wiring connections, and circuit breaker.
- Fixture feels loose:**
Re-tighten the mounting screws and decorative nuts.
- Glass shade wobbles:**
Tighten the shade screws evenly.
- Cord slips:**
Re-secure the cord lock and canopy set screw.

WARRANTY

1-Year Limited Warranty

This warranty covers defect in materials and workmanship under normal residential use. It does not cover improper installation, misuse, accidental damage, or normal wear. For support, contact customer service with your order number and product model.

THANK YOU FOR YOUR PURCHASE!

Contact customer service if you have any questions or need assistance.