

# Assembly Instruction


## ASSEMBLY TIPS:




1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

### ▲ Warning !


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

## PARTS IDENTIFICATION:



HARDWARE PACKAGE:			
NO	DESCRIPTION	FIGURE	QTY
1	ALLEN BOLT $\Phi 1/4 \times 10\text{mm}$		32pcs
2	LOCK WASHER $\Phi 1/4$		32pcs
3	ALLEN WRENCH $\Phi 1/4 \times 57\text{mm}$		4pcs

NOTE : QUANTITIES SHOWN ARE FOR FOUR CHAIRS



### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

#### ▲Warning !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

**STEP 1:** Use Allen bolts to assemble legs and back seat, remember to use lock washers. Then tighten them with Allen wrench.

