


# ASSEMBLY INSTRUCTIONS

Compression must wait for 72 hours before it can be unfolded, and it needs to be flapped by hand



**WF304864/ WF304865/ WF304866  
WF304867/ WF304868**

1. Thank you for choosing *our products*.

## 2. Return Policy



DO NOT RETURN TO THE STORE! Skip the process of returning your product and contact us directly for a replacement

If you find that parts of your order are missing or damaged, we will gladly ship any needed replacement parts free of charge.

If your product's quality does not meet your expectations or you have found any sort of defect, please contact our customer service department and let us know the details of your order and any issues encountered, we will try our best to provide you with a solution. Feel free to also directly contact our manufacturer concerning needed replacement parts and they will be happy to help provide you with a solution or answer any questions you may have.

## Recommendations Before Beginning Assembly



- Read instructions, cover to cover



- Have 2-4 adults on hand for assembly depending on product size



- Do not assemble directly on flooring or carpet



- Assemble on a clean non-marring surface (example: packing foam)



- Save all packaging until finished

## 3. Assembly Notice:











- If you encounter any problems during assembly and find that you cannot continue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the

parts of the product stored in a safe place and contact us immediately so we may assist you further.

- ☒ Once you have opened your package, remove all inner hardware packages and take the parts out. One by one, Place the parts out neatly in front of you, then refer to the instructions to ensure no parts are missing. If any pieces are found missing, please carefully look in the box first, as the hardware packaging might have torn making the hardware spill in the box.
- ☒ Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- ☒ **IMPORTANT:** When setting up your product, **DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING.** Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.
- ☒ When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.

#### Care & Maintenance

- ☒  Do not put hot items directly on furniture surface
- ☒  Do not clean furniture with harsh cleansers or polish
- ☒  Do not place furniture under direct sunlight
- ☒  Do not place furniture near heating or cooling vents
- ☒  Do not write on furniture without a padded barrier to protect the surface
- ☒  Do not place furniture outside. For indoor use only
- ☒  Not for commercial use. For residential use only
- ☒  Stains may be removed with mild soap solution and damp cloth



Children should not climb or jump on the furniture



Dust and pick-up spills using a clean, non-colored, lint-free cloth























#### Caution

● This product contains small components. Please ensure that they are kept away from small children.


● Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.



# PART LIST:

B		24PC
C		2PC
D		24PC
E		24PC
F		20PC
G		1PC
H		1PC
J		1PC
K		1PC
L		1PC
M		1PC
N		2PC
O		2PC
P		1PC
Q		1PC
R		4PC
S		2PC
T		4PC
W		20PC
X		1PC
Y		1PC
Z		1PC

**WF304864:**Lx1 Mx1 Rx1 Tx1  
**WF304865:**Jx1 Kx1 Rx1 Tx1  
**WF304866:**Nx1 Ox1 Rx1 Tx1  
**WF304867:**Nx1 Ox1 Rx1 Tx1  
**WF304868:**Qx1 Px1 Sx2 Bx24  
Cx2 Dx24 Ex24 Fx20 Gx1 Hx1  
Wx20 Xx1 Yx1 Zx1












Big backpack

Small backpack

Seat




① x 2









W  x 8	B  x 8	D  x 8
E  x 8	F  x 8	G  x 1

W F  
STEP4



②



W  x 4	B  x 4	D  x 4
E  x 4	F  x 4	G  x 1

W F  
STEP4

3



W x 2	E x 4
B x 4	D x 4
F x 2	G x 1
C x 1	



4


The data cable of the back speaker needs to pass through this hole






Come out of this hole

X

Wireless charging and USB connection



5



STEP2

STEP2

STEP4

W x 4

B x 4


D x 4

E x 4

F x 4


G x 1

6



STEP3


G  
E  
D




STEP2

STEP2

W  
F



The hole position is inside and the hand needs to be inserted for installation



STEP1

B

W x 2

B x 4

D x 4


C x 1

E x 4


F x 2


G x 1

7



8





Turn on the power switch and the Bluetooth device will start automatically, making a "ding ding ding" sound. Wait for about 5 seconds and the Bluetooth will automatically pair with your phone's Bluetooth. At this time, the Bluetooth section on your phone will display the word "Lucking". Select to connect, and after connecting, you will hear a prompt voice say "ding dong", indicating that the Bluetooth has successfully paired with your phone. Then, open the music player on your phone and you can listen to wonderful music.