


Overbed Height Adjustable Mobile Side Table Cart



## Models: OFF65921/29/39

Please contact Seville Classics for help with assembly and to report any damaged or missing components.


Phone: 1 (800) 323-5565 Email: Support@SevilleClassics.com Homepage: www.SevilleClassics.com

# Parts List

A. Base (1)			I. Long screw (4)	
B. Neck (1)			J. Medium screw (4)	
C. Top frames (2)	A. A		K. Short screw (4)	Company of the second sec
D. Top (1)			L. Washers (4)	0
E. Casters (2)			M. Nuts (4)	
F. Locking casters (2)			N. Split washers (4)	0
G. Large wrench (1)	Ľ		O. Knob (1)	
H. Caps (4)			P. Small wrench (1)	S.
		-	Q. Hex key (1)	

#### Please make sure you have all the parts on this list.

If you're missing parts, contact us for replacements at (800) 323-5565 or send an email to Support@SevilleClassics.com



B

σ



Attach pair of LOCKING CASTERS (F) to wide end of the BASE (A) using LARGE WRENCH (G).

Attach pair of CASTERS (E) to other side of the BASE (A) the same way.

#### STEP 2.

Place SPLIT WASHERS (N) over holes on top of **BASE (A)**.

Align holes on bottom of NECK (B) with split washers and holes on base.

Fit MEDIUM SCREWS (J) through the bottom of neck, split washers and base.

Hold MEDIUM SCREWS (J) with the HEX KEY (Q) and fasten with NUTS (M) using SMALL WRENCH (P). Tighten until snug.

Screw KNOB (O) into side of NECK (B).

#### STEP 3.


Press CAPS (H) into open ends of both TOP FRAMES (C).


Align holes of one TOP FRAME (C) with holes on side of **NECK (B)**. Attach with LONG SCREWS (I). Repeat for other TOP FRAME (C).

Tighten with **HEX KEY (Q)** until snug.









#### STEP 4.

Carefully place **TOP (D)** onto the **TOP FRAMES (C)** and line up the screw holes.

Fit WASHERS (L) over the SHORT SCREWS (K). Attach screws to TOP (D) through bottom of TOP FRAMES (C) and tighten with HEX KEY (Q).

> Congratulations! Enjoy your new Overbed Laptop Desk Cart!

### **Use Instructions**

- Move desk into desired position and lock the front casters.
- Turn the tension knob counter-clockwise to unlock height adjustment.
- Place hands on both sides of the top and pull up to lift; press down to lower the height.
- Turn tension knob clockwise until snug to secure the table height.

# Safety

**DO NOT** put more than 15 lbs. (evenly distributed) on the desk top. Remove items from desktop when adjusting height.

### Customer Service Information

Telephone: (800) 323-5565

Fax: (310) 533-3899

Hours: 8:30 AM – 4:30 PM (PST)

Email: <u>Support@SevilleClassics.com</u>

Homepage: www.SevilleClassics.com