










Please read these instructions and warranty information carefully before use and keep them properly for future reference.


OPERATING INSTRUCTIONS

Part List


A  41PCS	B  36PCS	C  2PCS	D  60PCS
E  8PCS	F  12PCS	G  7PCS	H  12PCS
I  38PCS	J  10PCS	K  2PCS	L  5PCS
M  21PCS	1  1PC	2  1PC	3  1PC
4  1PC	5  1PC	6  1PC	7  1PC
8  1PC	9  1PC	10  1PC	11  1PC
12  1PC	13  1PC	14  1PC	15  1PC
16  1PC	17  1PC	18  1PC	19  1PC
20  1PC	21  1PC	22  1PC	23  1PC
24  1PC	25  1PC	26  1PC	27  1PC
28  1PC	29  1PC	30  2PCS	31  2PCS
32  1PC			

Assembly Instructions


1




2



3




4




Assembly Instructions


5




6



7



8



Assembly Instructions

