


# SECURITYBARWB™ User Manual

## Window Security Lock Bar (Black)

SecurityMan®



### Introduction

SecurityMan window security bar is compatible with horizontal and vertical windows. The highly visual iron bar serves as a deterrent to intruders. Enjoy a lot or a little fresh air while keeping your window in a secure, fixed position. The bar is a great way to keep children safe by placing out of children's reach. All the hardware included for easy installation. The SECURITYBARWB security bar provides both safety and peace of mind for the entire family.

### Features

- Adjustable length: 14.25" to 37" inch.
- Easy and fast installation. Mounting hardware included.
- Child proof lock to keep kids safe inside.
- Allows window to be open for air circulation while keeping intruders out.



### Package Contents

- SecurityBarWB (2 parts)
- 2x Lift locks (4 parts; 2 metal plates & 2 black saddle mount)
- Double-side threaded screw
- Spacer (3/4" wide for narrow window frame)
- 3x End caps (black, plastic)
- 6x Philip screws (3/4" long)
- 3x Philip screws (2" long applicable for spacer)
- QSG

### Specifications

- Application: For sliding windows
- Adjustable length: 14.25" to 37" inch (14.25"-24.25" on 2 bars, 26.9"-37" on 3 bars)
- Size: Outer bar 1.0" x 1.0" / inner bars .75" x .75" (2 parts)
- Spacer: Yes 1.56"(L) x 0.75" (W) x 1.0" (H), 3 screw holes
- Anti lift lock: Yes (both ends)
- Force: 250lbs max pressure
- Gauge: 1/16" thick
- Material: High grade iron tube
- Color: Black
- Weight (net/gross): 1.43lbs / 2.43lbs

### Product basics



## Setup

Before you begin drilling holes please measure the distance of the window opening and determine whether or not you need to add the extension bar to the SECURITYBARWB. If the extension bar is needed, attach one end of the pre-drilled end caps to the end of the SECURITYBARWB and then screw the bars together using the threaded screw rod. If the extension is not needed please go ahead and attached the sealed cap to the end of the bar.

**NOTE:** If your window is 3/4" wide, please use the included spacer and 2" screws to secure lift lock, saddle catch and spacer. Be sure to also factor in the bar will be 1" longer when using the spacer.


### OPTION 1

1. With the window closed, place the bar about half way up from the bottom of the window, making sure the bar is leveled and mark a line on both ends of the window.

2. Match the black saddle saddle catch to the line and mark where the holes will go. Then drill 1/16" holes. Secure the lift lock and saddle catch (lift lock behind the saddle catch) with the provided screws on both side of the window.

3. Extend the bar to the width of the window and place it down on the saddle catch.


**CAUTION: PLEASE MAKE SURE THAT THE DRILL AND SCREWS DO NOT PENETRATE THE GLASS.**



### OPTION 2

Simply place the window security bar on your window track and extend the bar to secure.

**NOTE:** No drilling, no screws, no saddle mount, and no lift lock are needed for OPTION 2 setup.



### Warranty:

SecurityMan warrants that this product will be free from defects in materials and workmanship for one year or otherwise specified on the product packaging. This limited warranty shall commence from the date of purchase. SecurityMan Products warranty is not transferable and is limited to the original purchaser. If the product is found to be defective then, as your sole remedy and as the manufacturer's only obligation, SecurityMan will repair or replace the product. This warranty shall not apply to products that have been subjected to abuse, misuse, abnormal electrical or environmental conditions, normal wear and tear or any condition other than what can be considered normal use.

### Copyright Notice

This manual is furnished under license and may be used or copied only in accordance with the terms of such license. Except as permitted by such license, no part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or any means, electronic, mechanical, recording, or otherwise, including translation to another language or format, without the prior written permission of SecurityMan. The content of this manual is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by SecurityMan. SecurityMan assumes no responsibility or liability for any errors or inaccuracies that may appear in this book. All other product names, trademarks and registered trademarks in this document are the properties of their respective holders.

SecurityMan®  
4601 E. Airport Drive, Ontario, CA 91761, USA  
Tel: 888-977-3777 or 909-230-6668 Fax: 909-230-6889  
Email: [info@securitymaninc.com](mailto:info@securitymaninc.com) Website: <http://www.securitymaninc.com>  
Copyright 2021 by SecurityMan v2.2

If you encounter any difficulty in the operation of this product after reading the manual, please feel free to contact us. You can reach us by phone at 1-888-977-3777 from 8:30 AM to 5:30 PM Monday through Friday (Pacific Standard Time) or by email [techsupport@securitymaninc.com](mailto:techsupport@securitymaninc.com). We will be happy to answer your questions and help you in any way we can.

# For Customer Service: 888-977-3777