



Assembly & instruction Manual

SPU: SPC000174









96.45inch X 84.65inch X 59.05inch camping tent

Thank you very much for choosing **cobizi's** camping tents, after opening the box, please check the following accessories to see if they have their full, any problems with the product, please contact our service email!


Team mailbox: service@cobiziofficial.com

Have a nice trip !


Part & Accessories

NO	A	B	C	D	E	F
LIST	Long Frame Tube A 	Short Frame Tube B 	Rope 	Steel Peg 	Tent 	Bag 
QTY	2 PCS	1 PC	2 PCS	6 PCS	1 PC	1 PC


SET UP




Assemble the tent poles .




Put the tent poles(A) to the body of the tent through the sleeves ,forming an "x" shape over the tent.




Connect poles to the tent with the pins .




Clip plastic tent clips to the fiberglass poles (Do not clip to metal ferrule) .




Stake out the tent using included tent pegs .
Ensure tent mat is stretched flat at corners .



Insert the glass fiber (B) into the rain fly webbing, put the rain fly on top of the tent, and fix the rain fly one the top of the main tent with rope .



Link the S-Hooks at the end of the rain fly.



Tie out the rain fly sides using the webbing loops, fix the guy lines with tent peg.

Made in China

Warning: To avoid the potential dangers of suffocation, please keep allparts and packaging away from babies and children.