



TV Stand

889142951605

889142951377



ASSEMBLY INSTRUCTIONS

Before You Begin: Phillips screwdriver required (Not Included).

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a clean surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.


Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.













Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision. To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

Failure to detach this restraint before moving furniture may result in injury or damage.








DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE





PARTS

(1)X1  Top Panel	(2)X1  Bottom Panel	(3)X2 L R  Side Panel (L&R)	(4)X2  Door Stopper	(5)X1  Back Panel	(6)X1  Center Leg	(7)X4  Leg	(8)X1  Center Panel
(9)X1  Center Pillar	(10)X2  Shelf	(11)X2  Right Door	(12)X2  Left Door	(13)X2  Door Trim			



HARDWARE

(A)X14  Wood Dowel M8 x 30mm	(B) Hardware Packet Contents (B1)X14 (B2)X14   Male Camlock Female Camlock	(C)X8  Metal Shelf Support	(D)X4  CSK Screw M4 x 32mm	(E) Hardware Packet Contents (E1)X4 (E2)X4 (E3)X4    JCBB Spring Washer Flat Washer M8 x 60mm		
(F)X1  Allen Wrench M5	(G)X8  Soft Close Hinges 7/8	(H)X54  CSK Screw M3.5 x 16mm	(I) Hardware Packet Contents (I1)X4 (I2)X8   Handle Handle Screw		(J)X40  CSK Screw M3 x 16mm	Use if needed. See anti-tip kit packaging for instructions.  Anti-Tip Hardware



STEP 1 STEP 2




STEP 3	STEP 4
--------	--------




STEP 5	STEP 6
--------	--------




STEP 7




STEP 8




STEP 9




STEP 10




STEP 11




Screw Pattern




STEP 12




STEP 13




STEP 14




STEP 15



COMPLETED



DOOR ADJUSTMENT





Important:

This furniture includes an anti-tipping kit to help prevent tip-over accidents.

Use is recommended for safety, especially if children are present.

Use the anti-tipping kit as seen in the diagram below. Choose a suitable wall fixing that matches your wall style and then fasten the strap to the wall as shown using appropriate fixings.



Quality and Safety Guidelines

- Please follow the static and dynamic weight capacity limits provided on this item. If you are unsure of the weight capacities for this product, email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please use this item on a stable, level surface only. All parts of the base should contact the flooring surface when in use.
- Do not use this item if any instability is detected.
- This item is intended as a cabinet only, do not climb, stand or sit on this item.
- To prevent pinching or crushing injuries, please ensure fingers are away from the doors when shutting.
- Do not push or pull this item to move it, team lift to reposition.
- The item is intended to be used indoors.
- For maintenance instructions and replacement parts, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please review and retain all assembly instructions, safety and quality guidelines and product warnings for future reference.
- For product longevity, product safety and product integrity, protect from wet or humid weather and store indoors in a dry location. For additional storage instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please visit www.theubiquegroup.com for our product warranty details or email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please inspect this product regularly to make sure there are no damaged or worn parts. Also inspect to make sure all hardware is tightened correctly and securely. For inspection instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- If any parts are damaged or worn, please stop using the product. Repair this product with manufacturer supplied parts only.