



## ASSEMBLY INSTRUCTIONS

### UltraHD® Stacking Top Cabinet (Model No. UHD16248T, UHD16256T)

Granite


Graphite


36 in. W x 24 in. D x 18.5 in. H  
(91.4 cm x 61 cm x 46.9 cm H)

**ULTRAGUARD®**

FINGERPRINT RESISTANT SURFACES  
AND INCREASED DURABILITY


Reference page 10 for special care  
and maintenance of stainless steel






## PARTS LIST


Please check the parts carefully according to the parts list. If you are missing any parts, please contact our customer service department (Please refer to page 11).




(#1) Left Panel x 1 PC




(#2) Right Panel x 1 PC




(#3) Top Panel x 1 PC




(#4) Bottom Panel x 1 PC




(#6) Left Door x 1 PC



(#7) Right Door x 1 PC











(#8-A) Back Panel x 1 PC



(#23) Magnet x 2 PCS












## PARTS LIST

Please check the parts carefully according to the parts list. If you are missing any parts, please contact our customer service department (Please refer to page 11).

|                                                                                     |                                                                                       |
|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|    |    |
| <p>(#14-A) Left Back Upper Corner Protection D x 1 PC</p>                           | <p>(#15-A) Right Back Upper Corner Protection C x 1 PC</p>                            |
|   |    |
| <p>(#15) Corner Protection-A x 1 PC</p>                                             | <p>(#16) Corner Protection-B x 1 PC</p>                                               |
|  |   |
| <p>(#17-A) Left Front Bottom Corner Protection x 1 PC</p>                           | <p>(#18-A) Right Front Bottom Corner Protection x 1 PC</p>                            |
|  |  |
| <p>(#19-A) Right Back Bottom Corner Protection x 1 PC</p>                           | <p>(#20-A) Left Back Bottom Corner Protection x 1 PC</p>                              |

# PARTS LIST


Please check the parts carefully according to the parts list. If you are missing any parts, please contact our customer service department (Please refer to page 11).

|                                                                                     |                                                                                       |
|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|    |    |
| (#22) Key x 2 PCS                                                                   | (#27) Washer (M4) x 2 PCS                                                             |
|    |    |
| (#27-B) Washer (M8) x 2 PCS                                                         | (#41) Screw F (M4 x 8L) x 36 PCS                                                      |
|   |   |
| (#42) Screw G (M4 x 30L) x 8 PCS                                                    | (#54) Screw N (M4 x 10L) x 36 PCS                                                     |
|  |  |
| (#55) Screw M (M6 x 50L) x 2 PCS                                                    | (#55-A) Wall Anchor x 2 PCS                                                           |
|  |  |
| (#61) Screw O (M4 x 12L) x 2 PCS                                                    | (#60) Mounting Strap x 2 PCS                                                          |
|  |                                                                                       |
| (#21) Screw Driver x 1 PC                                                           |                                                                                       |

## UltraHD® Stacking Top Cabinet (Model No. UHD16248T, UHD16256T)




**\*NOTE: We recommend using TWO people to assemble the cabinet\***



**TIP: A magnetic screwdriver is included for your convenience. If a power screwdriver is used, keep on a low torque setting.**


### **Step 1: Install Right Panel (#2) to the Top Panel (#3)**

Place the Right Panel (#2) on the ground vertically. Make sure the front of the panel faces downward. Place the Top Panel (#3) next to the Right Panel (#2). Line up the screw holes, use 4 pcs of Screw F (#41) with Screw Driver (#21) to tighten.



### **Step 2: Install Left Panel (#1)**

Place the Top Panel (#3) and Left Panel (#1) vertically. Line up the screw holes, use 4 pcs of Screw F (#41) to tighten.




### **Step 3: Install Bottom Panel (#4)**

Attach the Bottom Panel (#4) to the Left and Right Side Panels (#1 and #2). Make sure the front of the panel faces downward. Use 8 pcs of Screws G (#42) to assemble the panels.

## UltraHD® Stacking Top Cabinet (Model No. UHD16248T, UHD16256T)




**\*NOTE:** We recommend using TWO people to assemble the cabinet\*




### Step 4: Install Back Panel (#8-A)

Place the Back Panel (#8-A) onto both Left and Right Side Panels (#1 and #2) and Top and Bottom Panel (#3 and 4). Use the 12 pcs of Screw F (#41) to tighten.



### Step 5: Install Magnet (#23)

Use 4 pcs of Screw F (#41) to install the Magnet (#23) on the Top Panel (#3) and the Bottom Panel (#4).



### Step 6: Install Left Door (#6)


Attach the Left Door (#6) to the Left Panel (#1), use 3 pcs of Screw F (#41) to tighten the Door Panel.

Note: The screw holes on the door hinge have tolerance, enabling the door to be adjusted and centered in the door frame.

## UltraHD® Stacking Top Cabinet (Model No. UHD16248T, UHD16256T)




**\*NOTE: We recommend using TWO people to assemble the cabinet\***



### Step 7: Install Right Door (#7)

Attach the Right Door (#7) to the Right Panel (#2), use 3 pcs of Screw F (#41) to tighten the Door Panel.

Note: The screw holes on the door hinge have tolerance, enabling the door to be adjusted and centered in the door frame.




### Step 8: Install the Corner Protection A & B (#15 & #16), and the Left & Right Back Upper Corner Protection C & D (#14-A & #15-A)

1. Use 6 pcs of Screws F (#41) to install the Left Back Upper Corner Protection D (#14-A) onto the left back top of the cabinet and install the Right Back Upper Corner Protection C (#15-A) onto the right back top of the cabinet.

2. Use 10 pcs of Screws N (#54) to install the Corner Protection A and B (#15 and #16) onto the front top of the cabinet.

**Note Fully tighten the screws after all the corner protections are attached.**




**Step 9:** Remove the top Corner Protection brackets from Model No. UHD16248B /UHD16256B Storage Cabinet as the left illustration shows.


## UltraHD® Stacking Top Cabinet (Model No. UHD16248T, UHD16256T)



**\*NOTE:** We recommend using TWO people to assemble the cabinet\*



**Step 10:** Remove the 2 pcs of Mounting Strap and screws from the top back panel of Storage Cabinet UHD16248B / UHD16256B.



### **Step 11: Attach Stacking Top Cabinet Model No. UHD16248T & UHD16256T**


A. Place Stacking Top Cabinet model # UHD16248T / UHD16256T on top of Storage Cabinet UHD16248B / UHD16256B.

B. Attach the Left Front Bottom Corner Protection (#17-A), Right Front Bottom Corner Protection (#18-A), Right Back Bottom Corner Protection (#19-A), Left Back Bottom Corner Protection (#20-A) on the bottom of the Stacking Top Cabinet connecting the Storage Cabinet, use 26 pcs of Screw N (#54) to tighten.

# UltraHD® Stacking Top Cabinet (Model No. UHD16248T, UHD16256T)



**\*NOTE: We recommend using TWO people to assemble the cabinet\***



## Step 12: Install Mounting Strap (#60)


A. Remove 1 pc of Screw F (#41) from each of the Left & Right Back Upper Corner Protection C & D ( #14-A & #15-A).

B. Attach the Mounting Strap (#60) to the back Corner Protection brackets as the left illustration shows using Screw O (#61) and Washer (#27).

C. Drill a hole in the wall with a 5/16" drill bit, insert the Wall Anchor (#55-A) into the hole.

D. Attach the other end of the Mounting Strap (#60) to the wall using Screw M (#55) and Washer (#27-B).

**Repeat steps A through D to install the other mounting strap.**





**Warning: To prevent possible tipping, it is suggested that the Mounting Straps be installed. For safety, secure the mounting straps to wood studs whenever possible.**

## UltraHD® Stacking Top Cabinet (Model No. UHD16248T, UHD16256T)



**\*NOTE: We recommend using TWO people to assemble the cabinet\***



| Total Weight Capacity<br>Stand Alone Unit - Not mounted<br>Evenly Distributed     | Total Weight Capacity<br>Mounted on Compatible Cabinet<br>on Leveling Feet Evenly Distributed |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
| 300 lbs. (136.08 kg)                                                              | 800 lbs. (362.87 kg)                                                                          |
|  |            |

### **Stainless Steel Maintenance:**

These parts have an UltraGuard® fingerprint resistant finish. Do not use traditional stainless steel cleaners on this unit. Lightly wipe off once a month with clean warm water and a soft cloth (preferably a microfiber cloth). This is the safest formula to prevent new stains from appearing over time and manage unwanted fingerprints or grease marks. Remember to always wipe in the direction of the surface grain (NEVER ACROSS) and always use a lint-free cloth. Once the surface is clean, thoroughly wipe dry with a soft absorbent cloth.

## CONTACT INFORMATION


If you are missing any parts, have any questions, or need additional assistance in assembly, please contact our bilingual (English and Spanish) customer service department at:




Seville Classics, Inc.  
19401 Harborage Way Torrance, CA 90501 USA  
Telephone: (800) 323-5565 within USA  
Fax: (310) 533-3899  
Hours: 8:30am - 4:30pm (Pacific Standard Time)  
E-mail: [support@sevilleclassics.com](mailto:support@sevilleclassics.com)  
Website & Online Store: [www.sevilleclassics.com](http://www.sevilleclassics.com)

**\*\*\*Please visit our website or call and inquire about our additional UltraHD® Line\*\*\***

## UltraHD® Line




**UltraHD® Tall Storage Cabinet**  
Model No. 16236 (Granite)  
Model No. 20143 (Graphite)  
Model No. 20153 (Red)  
Model No. 20133 (White)



**UltraHD® Mega Storage Cabinet**  
Model No. 16238 (Granite)  
Model No. 20148 (Graphite)  
Model No. 20158 (Red)  
Model No. 20138 (White)

# UltraHD® Line




**UltraHD® Rolling Cabinet**

**Model No. 20225 (Granite)**

**Model No. 20081 (Graphite)**

**Model No. 20082 (Red)**

**Model No. 20083 (White)**




**UltraHD® 6-Foot Height Adjustable Workbench**

**Model No. 20292 (Granite)**

**Model No. 20293 (Graphite)**

**Model No. 20134 (Red)**

**Model No. 20131 (White)**




**UltraHD® Wall Cabinet with Open Shelf**

**Model No. 20230 (Granite)**

**Model No. 20140 (Graphite)**

**Model No. 20150 (Red)**

**Model No. 20130 (White)**




**UltraHD® 2-Door Rolling Workbench**

**Model No. 20262 (Granite)**

**Model No. 20142 (Graphite)**


**Model No. 20152 (Red)**

**Model No. 20132 (White)**



**UltraHD® Trash Bin**

**Model No. 20215**



**UltraHD® Lighted Workcenter**

**Model No. 20247 (Granite)**

**Model No. 20246 (Graphite)**

**Model No. 20157 (Red)**