
furniturebox

SELENE

Small Sideboard

Assembly Guide



furniturebox

IMPORTANT: please read these instructions fully before starting assembly



SAFETY AND CARE ADVICE



NO POWER TOOLS

- Check you have all the components and tools listed
- Remove all fittings from their bags and separate into groups
- We do not recommend use of power tools - this could damage the unit. Only use hand screwdrivers and Allen keys
- Keep children and animals away from the work area, small parts could cause choking if swallowed
- Make sure you have enough space to lay out the parts before starting
- Assemble the item as close to its final position (same room) as possible
- Do not over tighten the nuts to avoid damage to the threads
- Only clean using a damp cloth and mild detergent. Do not use bleach or abrasive cleaners
- Do not allow children to climb or play on this product
- From time to time, check there are no loose screws in this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre
- Unless otherwise stated, this product is designed for domestic use and is not certified for commercial or contract settings

furniturebox

IMPORTANT INFORMATION



30 Minute Build



One Person Build



Max Weight Capacity 60kg


Note: Assembly estimates are approximate and can differ based on the specific environment and user experience.

furniturebox

WHAT'S IN THE BOX

Note: the quantities are the correct amount to complete the assembly. In some cases more fixings may be supplied than are required.

Getting to know your product:












furniturebox

WHAT'S IN THE BOX

Note: the quantities are the correct amount to complete the assembly. In some cases more fixings may be supplied than are required.

Parts Key:

Label	Part Name	Image / Drawing	Quantity
1	Top Panel		1
2	Bottom Panel		1
3L&3R	Side Panel		2
4	Divider Panel		1
5	Left Shelf		1



Label	Part Name	Image / Drawing	Quantity
6	Right Shelf		1
7	Left&Middle Back Panel		2
8	Right Back Panel		1
9	Door Panel		3

furniturebox

WHAT'S IN THE BOX

Note: the quantities are the correct amount to complete the assembly. In some cases more fixings may be supplied than are required.

Hardware Key:

Label	Hardware Description	Image / Drawing	Size(mm)	Quantity
G	Hinges			4
H	Shelf Pins			8
L	Push Open			3
M	Hinges			2
N	Back Panel Clips			10
P	L-Bracket Kits			2
Q	Foot Pads		Ø50mm	5
S	Legs		Ø80mm	5
Z	Cam Lock Sticker		Ø20mm	24


furniturebox

Note:


- Use a clear, flat surface to avoid bumps or scratches before assembling.
- Insert all fixings loosely at first to allow for alignment; only tighten them once everything is properly positioned, as some adjustment may be required.
- Avoid over-tightening, as this may damage the parts.
- Seek assistance when moving large or heavy parts

Fitting Assembly Instructions


Assembly




Push connector into housing to join.




Make sure there is no gap between the panels.



Disassembly







furniturebox

STEP 1

Attach 5 x Legs [S] on panel [2].







furniturebox

STEP 2

Attach the 5 x **foot pad [Q]** to the legs [S].




Q	5pcs





furniturebox


STEP 3

First disassemble the hinges [M/G] to 2 components.
Attach 2 x Hinges [M] to Divider panel [4] as shown.
Attach 4 x Hinges [G] to Side panels [3L] and [3R] as shown.










Please ensure full alignment with the pre-drilled holes.

furniturebox

STEP 4


Attach Left side panel [3L] and Right side panel [3R] to Bottom panel [2] as shown.



furniturebox

STEP 5


Attach **D**ivider panel [4] to **B**otto**m** panel [**2**] as shown.




furniturebox

STEP 6

Attach Back panel [8] to Bottom panel [2], Divider panel [4] and Right side panel [3R] as shown.







furniturebox

STEP 7

Attach Back panel [7] to Bottom panel [2], Divider panel [4] and Left side panel [3L] as shown.







furniturebox

STEP 8

Attach 3x Push-open [L] to Top panel [1] using 6 x Screws with a Phillips Head Screwdriver.



L	3pcs




furniturebox

STEP 9

Attach Top panel [1] to Left side panel [3L], Right side panel [3R] and Divider panel [4] as shown.

Make sure Back panels [7] and [8] are fixed in the groove of Top panel[1].


Note: The sideboard will be permanently assembled once the panels are fitted.




furniturebox

STEP 10

Attach Back panel clips [N] and to Back panel [7] and [8] as shown.





N	10pcs



furniturebox

For safety, this unit should be securely affixed to the wall using appropriate fixings for your wall type. **Before drilling, always check for hidden pipes and electrical wires in the wall to avoid damage or injury.** If in doubt, please consult a professional or seek advice from your local hardware store.







furniturebox


STEP 11


1. With assistance, carefully move the assembled unit into its final position.
2. Position wall bracket [P1] against the rear of the assembled unit and mark the fixing position on the wall.
3. Check for hidden pipes or cables before drilling. If it is safe to do so, drill the wall at the marked position and insert wall plug [P4].
4. Secure wall bracket [P1] to the wall using screw [P2] and washer [P3], fixing into wall plug [P4].
5. Secure wall bracket [P1] to the inside of the unit using screws [P5] and washer [P3].


Warning: The supplied wall fixings may not be suitable for your wall type. Always use fixings appropriate for your wall construction. If in doubt, seek professional advice.































furniturebox

STEP 12

Tighten 8 x Shelf pins [H] into Left side panel [3L], Divider panel [4] and Right side panel [3R].
Place Shelf panel [5] and [6] into the cabinet as shown by resting on the shelf pins.




H	8pcs




furniturebox


STEP 13


Attach **4** x Hinges [**G**] to Left side **d**oor [**9**] and **Right side d**oor [**9**] using **8** x Screws with a Phillips Head Screwdriver.
Attach 16 x **Cam lock sticker [Z] to Left side door [9] and Right side door [9].**



G	4pcs	Z	16pcs









Please ensure full alignment with the pre-drilled holes.


furniturebox

STEP 14

Attach 2 x Hinges [M] to Middle door [9] using 4 x Screws with a Phillips Head Screwdriver.
Attach 8 x Cam lock sticker [Z] to Middle door [9].









Please ensure full alignment with the pre-drilled holes.

furniturebox

STEP 15

Attach Left side door [9] and Right side door [9] to Left side panel [3L] and Right Side panel [3R].







furniturebox

STEP 16


Attach Middle door [9] to Divider panel [4].






STEP 17

After transportation the push-to-open magnetic latches may require adjustment if they are not working. See diagrams below. To adjust the latches, please push and release the piston once to allow it to extend outwards. Once extended, gently turn the piston clockwise or anti-clockwise to correct its position.
Close and open the door to confirm magnetic latch is functioning correctly.







furniturebox

STEP 18

Adjust the door panels upward or downward




1.




Unscrew 2 screws in round holes slightly loosen the screws within the oval shaped hole

2.




MOVE DOOR UPWARD OR DOWNWARD

3.




Tighten 2 screws in oval holes. Screw in 2 screws in round holes.

Adjust the gap between door panel and side panel




1.




Move door outward by turning this screw counter-clockwise

2.




KEEP DOOR IN RIGHT POSITION

3.




Move door inward by turning this screw clockwise


Adjust the door back and forth



1.




2.



MOVE DOOR BACK OR FORTH

3.




Rotate this screw to move doors back or forth

furniturebox

STEP 19

Your Sideboard is complete and ready to use.



Please ensure any and all fixings and fittings are FULLY tightened before using this product

our 2 year GUARANTEE

Our products come with a 2 year guarantee, giving you extra peace of mind when shopping with us!

What the guarantee covers

PRE-INSERTED FIXINGS
e.g. loose metal threads

FAULTY JOINTS
e.g. legs bending

EXTERNAL FIXING FAULTS
e.g. metal discs removing from table top

STRUCTURAL INTEGRITY
e.g. the frame of the product

Activate your Guarantee

Scan the QR code to read the full guarantee online and register your product. It only takes a moment to fill out.
Or visit: furniturebox.co.uk/our-guarantee

Furniturebox Unit 6, Indurent Park Chippenham, Clanville Way, Chippenham, SN15 5BD, UK
Telephone: 01747 863 333 **Email:** sales@furniturebox.co.uk