DINING CHAIR ASSEMBLY INSTRUCTION

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present.

IMPORTANT: PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

"DO NOT OVERTIGHT ANY HARDWARE"

WARNING: SMALL PARTS AND HARDWARE NOT FOR CHILDREN UNDER 3 YEARS, ADULT ASSEMBLY REQUIRED.

WARNING: SMALL PARTS AND HARDWARE NOT FOR CHILDREN UNDER 3 YEARS. ADULT ASSEMBLY REQUIRED.	
TABLE OF CONTENTS	
HARDWARES LIST	PAGE 2
PARTS LIST	PAGE 3
PARTS' LOCATION	PAGE 4
ASSEMBLY STEPS	PAGE 5 - 6
ASSEMBLY COMPLETED	PAGE 6
ASSEMBLY TOOLS REQUIRED	
1. Screwdriver (not provide)	2. Hammer (not provide)

Skip the power trip this time.



DINING CHAIR ASSEMBLY INSTRUCTION HARDWARES LIST ITEM DESCRIPTION DRAWING QTY 8 PCS Α JCBC SCREW M6 x 30MM В 8 PCS JCBC SCREW M6 x 55MM C 16 PCS WOOD DOWEL M8 x 30MM D SPRING WASHER M6 x 12MM 16 PCS Ε 12 PCS CSK C/B SCREW (M4 x 32MM) F 8 PCS **BARREL NUT**

There are total THREE (3) packs of hardware packs. Each hardware pack includes the hardware for TWO (2) chairs.

G


M4 ALLEN KEY (100MM)


1 PC

DINING CHAIR ASSEMBLY INSTRUCTION **PARTS LIST** QTY ITEM DESCRIPTION DRAWING LEG (LEFT) 6 PC 1 LEG (RIGHT) 2 6 PC 3 12 PC SUPPORT RAIL 6 PC **BACK PANEL** 4 6 PC 5 SEAT

DINING CHAIR ASSEMBLY INSTRUCTION


PARTS' LOCATION






DINING CHAIR ASSEMBLY INSTRUCTION









ASSEMBLY COMPLETED

PAGE 6 OF 6