Operating Instructions

Caution : You must read this before you proceed

Care & Maintenance


• Do not put hot items directly on furniture surface.


• Do not clean furniture with harsh cleansers or polish.


• To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.


• Children should not climb or jump on the furniture.


• Do not write on furniture without a padded barrier to protect the surface.


• To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and/or place under patio or awnings.


• Not for commercial use. For residential use only.


• Stains may be removed with mild soap solution and damp cloth.



• Keep away from sources of ignition.


• Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.


ASSEMBLY INSTRUCTIONS

BENCH






N761P539394




Detail View




Part list


1  2PCS Side Frame	2  1PC Stretcher	3  1PC Seat Frame

Hardware List

A 	B  Ø8 X 30mm	C  M6 X 50mm
Adjustable Leveling Foot (4PCS) + 1PC	Wooden Dowel(4pcs) + 1PC	Hex-Head bolts (6pcs) + 1PC
D 	M  M6 X 80mm	E 
Barrel Nut(2pcs) + 1PC	Hex Socket Set Screw, Full Thread (2 pcs) + 1PC	Flat washer(6 pcs) + 1PC
F 	K 	
Flat washer(6 pcs) + 1PC	Hex nut (2PCS) + 1PC	
		


ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)

 (Phillip head screwdriver)




PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN YOU USE POWER TOOLS !

STEP 1:




STEP 2:




STEP 3:

B	D
4PCS	2PCS




STEP 4:

K
2PCS



STEP 5:

C	E	F
6PCS	6PCS	6PCS



Ensure all bolts on the bench are securely tightened.