


Assembly Manual




Dining-Table





IMPORTANT INFORMATION!
please read the entire manual before starting to assemble and/or using this product.follow the manual thoroughly and keep it for further reference.







AVOID SCRATCHES!
In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.






IMPROVE EFFICIENCY !
Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.







ANTI-TOPPLE WARNING !

Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !


It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.


For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.

'SAFETY TIPS:

Static charge may cause duston foam- clean with a dry or damp cloth.
Smafoam strands may oepresent - handle gently and dispose of properly.
Do not burn or incinerate.
Check local recycling quidelines.
















friendly reminder


To avoid errors and confusion during the installation of accessories, use the type and quantity of hardware accessories according to the installation procedure described in the instructions. First, unroll the accessories bag and lay out the hardware accessories, cut holes in the side, and take out the hardware accessories

Packaging Details




A	X4+1	B	X2	C	X22+2	D	X36+3	E	X24+2	F	X1
	M4*14mm				Ø6x30mm		Ø5x38mm		M6x12mm		M3

G	X4	H	X2	I	X8+1	J	X1	K	X16+2		X1
					ϕ4x35mm		M4		ϕ3x14mm		

S	X2
	

Step 01




F	
	M3

D	X4
	Ø5x38mm

C	X4
	Ø6x30mm

Step 02




F	
	M3

D	X4
	Ø5x38mm

C	X4
	Ø6x30mm

Step 03




F	
	M3

D	X6
	Ø5x38mm

C	X4
	Ø6x30mm

Step 04

x2




A	X4
	M4*14mm


B	X2

First align the hole and then lock it


Step 05



After lowering the door panel, you can move it left and right to adjust its position so that it fits better into the groove. Make sure that the door panel is fully inserted into the groove




Step 06



After lowering the door panel, you can move it left and right to adjust its position so that it fits better into the groove. Make sure that the door panel is fully inserted into the groove


Step 07



F	
	M3

D	X4
	Ø5x38mm

Step 08



F	
	M3

D	X12
	Ø5x38mm

C	X6
	Ø6x30mm

Step 09

C	X4
Ø6x30mm	


F	
M3	

D	X6
Ø5x38mm	


If installation is difficult, pull on both door panels to adjust them to the optimal position

Step 10


Instructions for use of the tracks




S	X2



Step 11



Pull open the wire lock screw by hand




Hold the rail with your hand and tighten the screw


S	X2

J	
	M4

E	X4
M6x12mm	




Step 12




J	
	M4

E	X4
M6x12mm	


Step 13




correct




wrong




x2







correct





wrong







Step 14










80% festziehen






Step 15








80% festziehen


J	
	M4

E	X4
M6x12mm	

Step 16





Step 17







Step 18










80% festziehen







Step 19









80% festziehen







Step 20




Step 21

If installation is difficult, the boards can be assembled vertically





Step 22


K
ϕ3x14
I
ϕ4x35


K
K
G
correct
wrong
②
②
wrong
correct
wrong
correct

K
X8
ϕ3x14mm


G
X2

Step 23

Precautions for use




Step 24






Align desktop 1 and desktop 2, and then tighten the screw E that was not tightened in step 14.15.18.19 to 100%


Step 25



Step 26




Step 27






Step 28






Step 29







Step 30




Step 31





Lock Open




Open the track Lock the track


Instructions for using the lock buckle

Track locking device


Step 32



Step 33




Step 34







Step 35




Step 36



Step 37



Step 38



Instructions for using the lock buckle

Track locking device