
Assembly Instructions

Caution: You must read this before you proceed


DINING TABLE



Part List				
Label	Picture	Description	QTY	
Α		Table Top	1	
В		Table Leg	4	


С		Leg Support	2		
Hardware					
Label	Picture	Description	QTY		
1		Bolt (M8 x 40mm)	21		
2		Allen Key (M5)	1		
3		Wood Dowel (M10 x 40mm)	9		
Assembly Preparation					
Before Beginning Assembly:					
Read instructions, cover to cover- Have 2 adults on hand for assembly- Do not assemble on flooring or carpet- Assemble on a clean non-marring surface (packing foam)- Save all packaging until finished-					

Assembly Steps



This Dining Table has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the Dining Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.





Unpack and place the Table Top(A), Table Legs(B) and Table Supports(C) on a clean, non-marring surface.

Insert Wooden Dowels(3) into the four Table Legs(B) as shown.

Note: The Dining Table and its parts are Heavy, two adults are required whenever moving or lifting them.


Step 2

Place the Leg Support(C) onto the Table Legs(B) as pictured. Attach Table Leg(B) to Leg Support(C) Bolts(1) with Allen Key (2).

Do not fully tighten the Bolt.

Repeat this same process with the other Leg Support and Table Legs.

Note: The Dining Table and its parts are Heavy, two adults are required whenever moving or lifting them.




3.1: Place the Table Top(A) facedown on a clean, non-marring surface to avoid any scratches or damage to the product and place the Table Legs(B) and Table Supports(C) facedown onto the Table Top(B) as shown. 3.2 Attach Table Supports(C) to Table Top(B) using Bolts(①) with Allen Key(②).

Now Tighten all Bolts at all joints in a sequential manner.

Note: The Dining Table and its parts are Heavy, two adults are required whenever moving or lifting them.


Step 4



Your Dining Table is now ready for use.

This Dining Table can only be used on a flat, level surface.

Care & Maintenance



Do not clean furniture with harsh cleansers or polish.

Do not place furniture under direct sunlight.

Do not place furniture near heating or cooling vents.

Do not write on furniture without a padded barrier to protect the surface.

Do not place furniture outside . For indoor use only .

Not for commercial use. For residential use only .

Stains may be removed with mild soap solution and damp cloth.

Children should not climb or jump on the fumiture.

✓ Dust and pick-up spills using a clean, non-colored, lint-free cloth .