


INSTRUCTION MANUAL







| Help stand function

| Massage and fever

| Reclining function



Package list

PART		QTY
A		1PC
B		1PC
C		2PCS
D		1PC
E		1PC
F		1PC
G		1PC

Before Assembly

Note: Due to large size, The Recliner Chair comes with 2 parcels arrive, another parcel arrives on the same day. If not, it will arrive within 1-2 days. Please wait patiently or contact us at any time.

1. Keep this instruction manual for future reference
2. It is important to only use this product on a firm, level surface
3. Keep all small parts out of reach of children and animals
4. Make sure you have all the components, as listed in this instruction manual, if not, contact us at any time.
5. Remove all packaging and place the components on top of the empty box or on a clean floor to prevent them from becoming scratched
6. Make sure you have the right tools and a clean, dry and spacious area for assembly
7. Assemble on a flat/firm surface to avoid damage.
8. Assemble in the room you intend to use the chair or as close as possible to that room
9. Carefully follow each assembly step in the correct order to prevent incorrect assembly
10. Before use, ensure that the product is fully assembled and only then should the screws and bolts be fully tightened but not over tightened.
11. Do not discard any packaging until the product is fully assembled. This will avoid disposing of any parts
12. Do not use or attempt to assemble this product if parts are missing, damaged or worn. Please email sales@reclinerchair.com

Important Safety Instructions

If you have any concerns regarding your health, consult your doctor before using this product. Individuals with pacemakers should not use this product.

If you experience pain in a muscle or joint for a prolonged period of time. Discontinue use and consult your doctor.

Persistent pain could be a symptom of a more serious condition.

When using an electrical appliance, basic precautions should always be followed, including the following:

1. This product is for use on a 12V circuit. Make sure that the product is connected to an outlet having the same configuration as the plug.
2. Always unplug the massager from the power source after use, and before cleaning.
3. Do not reach for massager if it has fallen into water. Unplug immediately.
4. An appliance should never be left unattended when plugged in. Unplug from outlet when not in use, before putting on or taking off parts or attachments.
5. Do not use outdoors.
6. Do not carry this appliance by supplied cord as a handle.
7. Keep the cord away from heated surfaces.
8. Close supervision is necessary when this appliance is used by or near children, invalids or disabled persons.
9. This unit is not a toy. Children should not use it or play with it.
10. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
11. Do not use near eyes or other highly sensitive areas.
12. Keep cord away from heated surfaces.
13. Use this appliance only for its intended use as described in this manual. Do not use attachments not provided with the unit.

To store

1. Place unit in its box or safe, dry, cool place. Avoid contact with sharp edges or pointed objects which might cut or puncture the fabric. Do not wrap power cord around the unit.
2. Do not hang the unit by power cord.


To clean

1. Insure the unit is unplugged from the power source, and allow to cool before cleaning.
2. Do not place in any liquid to clean. Clean fabric cover by wiping with a damp sponge, using a mild detergent or suds. Pat dry with clean, dry cloth.
3. Do not use abrasive cleaners, brushes, gasoline, kerosene, glass /furniture polish, paint thinner or water hotter than 120 °C to clean the unit.
4. To clean the unit, make sure the massager is unplugged. Allow the unit to cool and the wipe down with a damp clean cloth. Do not use any strong chemical cleaners.

✂ Product Assembly

Step 1

Turn over the base part, you will find the power wire and controller wire are binding by three cable ties. Please cut off the #1, #2 & #3 cable ties.




Product Assembly

Step 2




the part C Armrest onto part A seat and insert the two metal pegs on the seat into the clips on the backrest with a click.





Step 3

Place the part B backrest onto part A seat and insert the two metal pegs on the seat into the clips on the backrest with a click.





Step 4



No.1 and No.2 wires on Part A
connect with No.1 and No.2 wires on Part B .
No.3 wire connects with part E .
No.4 wire connects with part D .


Step 5



No.1 wires on Part G
connect with No.1 wires on Part A .
No.2wires on Part F
connect with No.2 wires on Part A .


Step 6

Press and hold the recline remote control to achieve your desired angle





Remote



- **INTENSITY**: Switch between HIGH/LOW intensity massage.
- **MODE**: Select 5 types of massages, PULSE, PRESS, WAVE, AUTO or NORMAL.
- **BACK, LUMBAR, THIGHS, and LEGS**: Target massages to specific areas.
- **TIMER**: The default timing is 15-30-60 min selection,

⚠ NOTE:

- 1: When the time you choose is reached, it will automatically stop working.
- 2: DO NOT use for more than 60 minutes of continuous use.
- 3: When the heat reaches 60°C, it will automatically stop working.



Product Feature


- Heating massage
- 8 Vibration Motors
- 5 Massaging modes
- 2 Massaging intensity
- 4 massage zones, each zone can be operated individually
- The default timing is 15-30-60 min the selection



How to use

- 1、 Insert adapter jack into the socket found on back of the massage chair, then plug the adapter into a wall outlet.

(see Figure A)



- 2、 Turn the unit ON by pressing the POWER button once, The LED will illuminate when power is on.
- 3、 Turn on the massage in each zone by pressing the BACK, LUMBAR, THINGS or LEGS buttons. LEDS will illuminate when each zone is activated.
To turn off a zone, press the button again.
- 4、 To choose a desired massage mode, press the MODE button. To change modes, press MODE button until LED for desired mode illuminates.
PULSE-for deep tapping massage
PRESS-provides rapid tapping massage
WAVE-for a gradual, side-to-side vibrating massage
AUTO-automatic selection of different massages
NORMAL-gentle percussive massage
- 5、 To change the massage intensity press the INTENSITY button. The LED for HIGH or LOW intensities will illuminate when chosen.
NOTE: Discontinue use immediately if you feel any discomfort or pain.
- 6、 **NOTE:** for your benefit, the massage chair is equipped with an auto shut-off feature
- 7、 DO NOT use for more than 60 minutes of continuous use.

Frequently Asked Questions

1.What if my power lift recliner does not operate at all?

A:Ensure the external transformer is plugged into a properly wired electrical outlet.

A:Check the circuit breaker box connected to the electrical outlet to ensure the outlet is receiving power.

2.What is weight limit?

A:350LBS/150KG

3.Where can I get a replacement remote?

A:Please email us: chenhui@tjlxintl.com

4.I received only the top of the chair today. How soon will the bottom be shipped?

A:The chair comes with 2 boxes and we ship them on the same day,
but the carrier may deliver them to your door on different days.

if not,Please email us: chenhui@tjlxintl.com

5.Stopped working!

A:When the time you choose is reached, it will automatically stop working.

A:When the heat reaches 60℃, it will automatically stop working.

A:Ensure the external transformer is plugged into a properly wired electrical outlet.

A:Check the circuit breaker box connected to the electrical outlet to ensure the outlet is receiving power.

Thank you for using!